



## E40D INDEX

DESCRIPTION.....	4
DIAGNOSIS AND TESTING.....	9
TEARDOWN.....	36
ASSEMBLY.....	50
VALVE BODY.....	66
COMPONENT ASSEMBLY.....	68
SPECIFICATIONS.....	108

***AUTOMATIC TRANSMISSION SERVICE GROUP***  
**18639 S.W. 107TH AVENUE**  
**MIAMI, FLORIDA 33157**  
**(305) 670-4161**

Copyright © ATSG 1999



*Updated  
August, 2003*

## INTRODUCTION

### FORD E4OD

The FORD E4OD automatic transmission is a four speed unit with total electronic shift control and is designed for operation in longitudinal powertrains for rear wheel drive applications. The E4OD is currently found in "F" Series Trucks and "E" Series Vans.

The E4OD transmission features a four element torque converter design that includes Torque Converter Clutch (TCC) and a gear train that includes three planetary gearsets. The hydraulic control systems of the E4OD transmission has five electronically controlled solenoids for: Shift feel (through line pressure control), Shift scheduling (through shift valve position control), Engine braking during coast operation (through shift valve control) and TCC apply (ON/OFF).

***Note: There have been many engineering changes in this transmission since its introduction in 1989. ATSG also has available an "Update Handbook" which includes the many changes and is required along with this manual for a proper overhaul or repair.***

***We wish to thank Ford Motor Company  
for the information and illustrations  
that have made this booklet possible.***

No part of any ATSG publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means, including but not limited to electronic, mechanical, photocopying, recording or otherwise, without **written** permission of Automatic Transmission Service Group. This includes all text illustrations, tables and charts.

***The information and part numbers contained in this booklet have  
been carefully compiled from industry sources known for their  
reliability, but ATSG does not guarantee its accuracy.***

***Copyright © ATSG 2003***

**DALE ENGLAND**  
FIELD SERVICE CONSULTANT

**WAYNE COLONNA**  
TECHNICAL SUPERVISOR

**PETER LUBAN**  
TECHNICAL CONSULTANT

**JON GLATSTEIN**  
TECHNICAL CONSULTANT

**JERRY GOTT**  
TECHNICAL CONSULTANT

**GERALD CAMPBELL**  
TECHNICAL CONSULTANT

**JIM DIAL**  
TECHNICAL CONSULTANT

**ED KRUSE**  
TECHNICAL CONSULTANT

**GREGORY LIPNICK**  
TECHNICAL CONSULTANT

**DAVID CHALKER**  
TECHNICAL CONSULTANT

**ROLAND ALVAREZ**  
TECHNICAL CONSULTANT


**MIKE SOUZA**  
TECHNICAL CONSULTANT

***AUTOMATIC TRANSMISSION SERVICE GROUP***  
**18639 S.W. 107TH AVENUE**  
**MIAMI, FLORIDA 33157**  
**(305) 670-4161**





## E4OD



### E4OD Automatic Transmission

The E4OD Transmission is a fully automatic, electronically controlled, four-speed unit with a three element locking torque converter. The main operating components of the E4OD transmission include a converter clutch, six multiple-disc friction clutches, one band, two sprag one-way clutches and a roller one-way clutch which provide for the desired function of three planetary gear sets.


Transmission gear selection in the  $\odot$  range and converter clutch operation is controlled by the EEC-IV control system. Operating conditions are relayed to EEC-IV by various sensors throughout the vehicle. The EEC-IV compares these conditions with electronically stored parameters and logically determines the state that the transmission should operate at.

In the  $\odot$  range, automatic operation of all four gears is possible. The Overdrive Cancel Switch, located on the vehicle's dashboard, disables overdrive operation and enables automatic operation through the first three gears.

Manual gear selection is available in the 1 and 2 range. Second gear is commanded when the gear selector is in the 2 range and when downshifted into the 1 range at speeds above approximately 56 Km/h (35 mph) (for diesel 48 Km/h (30 mph). First gear is commanded in the 1 range at startups and when downshifted into 1 range below approximately 56 Km/h (35 mph) (for diesel 48 Km/h (30 mph).

NOTE: Any reference to Intermediate Brake Drum and Direct Clutch Cylinder are one and the same

## Thrust Washer and Needle Bearing locations




### BASE NUMBERS

### DESCRIPTION


7D014	THRUST WASHER - PUMP SUPPORT
7E486	NEEDLE BEARING - SUN GEAR
7G400	THRUST WASHER - OVERDRIVE PLANETARY CARRIER
7G128	NEEDLE BEARING - CENTER SHAFT
7G178	NEEDLE BEARING - CENTER SUPPORT
7L326	THRUST WASHER - CENTER SUPPORT
7G401	THRUST WASHER - INTERMEDIATE ONE-WAY CLUTCH
7D428	THRUST WASHER - INTERMEDIATE BRAKE DRUM
7F374	NEEDLE BEARING - FORWARD CLUTCH (PLASTIC) CYLINDER
7F078	NEEDLE BEARING - SUN GEAR
7D090	THRUST WASHER - FORWARD CLUTCH HUB
7D423	THRUST WASHER - PLANETARY CARRIER
7E413	NEEDLE BEARING - OUTPUT SHAFT HUB
7B368	THRUST WASHER - OUTPUT SHAFT

## E4OD AUTOMATIC TRANSMISSION



## AUTOMATIC TRANSMISSION SERVICE GROUP

## E4OD Automatic Transmission



E4OD EXPLODED VIEW





# Technical Service Information

## E40D EXPLODED VIEW LEGEND

1	7005	CASE ASSEMBLY	50.	7G387	COAST CLUTCH CYLINDER ASSEMBLY
2	7034	VENT ASSEMBLY	51	7A548-JA	SEAL — INNER
3	7086	GASKET — EXTENSION HOUSING	52	7A548-EA	SEAL — OUTER
4	7A039-CB	EXTENSION ASSEMBLY (4X2)	53	7G419	PISTON
5	7A041	— EXTENSION & BUSHING ASSY	54	7N519	RING — PISTON APPLY
6	7A040	— EXTENSION	55	7B070-EA	RING — RETAINING
7	7A039-DA	EXTENSION ASSEMBLY (4X4)	56	N804949-S	PLATE — COAST CLUTCH EXTERNAL SPLINE
8	7A039-EA	EXTENSION ASSEMBLY (SUPERDUTY)	57	7B442-CA	PLATE — COAST CLUTCH INTERNAL SPLINE
9	7H1102	BRACKET — WIRING	58	7B164-CA	PLATE — COAST CLUTCH PRESSURE
10	7034	BUSHING — EXTENSION HOUSING (4X2)	59	7B437-CA	RING — RETAINING (SELECTIVE FIT)
11	7052	SEAL — EXTENSION HOUSING (4X2)	60	N804950-S	RING — RETAINING
12	N605802-S36	BOLT — EXTENSION (4X2 BOTTOM) (2 PCS) M10X1.5X35MM	61	N804951-S	RING — RETAINING
13	N606569-S36	BOLT — EXTENSION (SUPERDUTY & 4X4 BOTTOM) (2 PCS) M10X1.5X90MM	62	N804952-S	GEAR — OVERDRIVE SUN
14	N605803-S36	BOLT — EXTENSION (TOP) (7 PCS) M10X1.5X40MM	63	777300-S	RING — RETAINING
15	7F293	SENSOR — MANUAL LEVER POSITION	64	377155-S	RING — RETAINING (OVERDRIVE OWC TO OUTER RACE)
16	N805312-S100	BOLT ASSEMBLY (2 PCS) M6X1.0X30MM	65	7G389	RACE — OVERDRIVE ONE WAY CLUTCH OUTER
17	7B498	SEAL — MANUAL LEVER	66	7G381	CLUTCH ASSEMBLY — OVERDRIVE ONE WAY
18	N805331-S	STUD — CASE TO SOLENOID BODY (1 PC) M6X1.0X79MM	67	7G388	RACE — OVERDRIVE ONE WAY CLUTCH INNER
19	7E195	BALL — RUBBER CHECK (10 PCS) (2 IN MAIN CONTROL)	68	7G400	WASHER — THRUST
20	379581-S	BALL — STEEL CHECK (1 PC.)	69	7E031	CARRIER ASSEMBLY — OVERDRIVE PLANETARY
21	N805330-S	STUD — CASE TO CONTROL ASSEMBLY (4 PCS) M6X1.0X61.25MM	70	7L676	CARRIER
22	7D017	EPC BLOW-OFF SPRING	71	7D008-CA	— PLANET GEARS (4 PCS)
23	353078-S	GASKET — SEPARATOR	72	7A238-CA	— PLANET SHAFTS (4 PCS)
24	7D100	PLATE — SEPARATOR	73	7A242-AA	THRUST WASHERS (8 PCS)
25	7A008	GASKET — SEPARATOR	74	7D037-BA	NEEDLE BEARINGS (80 PCS)
26	7C155	SCREEN — SEPARATOR	75	380225-S	— RETAINING PINS (4 PCS)
27	7G308	PLATE — SEPARATOR PLATE REINFORCING	76	7E486	NEEDLE BEARING ASSEMBLY
28	7F282	BOLT (3 PCS) M6X1.0X16MM	77	7G128	NEEDLE BEARING ASSEMBLY
29	N605772-S	SOLENOID BODY ASSEMBLY	78	7G382	GEAR — OVERDRIVE RING
30	N805329-S	BOLT — TORX HEAD (9 PCS) M6X1.0X40MM	79	7G375	RING — RETAINING (CENTER SHAFT TO OVERDRIVE RING)
31	7A100	MAIN CONTROL BODY ASSEMBLY	80	7G178	GEAR
32	N805326-S	BOLT (18 PCS) M6X1.0X42.5MM	81	7B421	NEEDLE BEARING ASSEMBLY
33	7G422	ACCUMULATOR BODY ASSEMBLY	82	7B066-BB	RING — OVERDRIVE RETAINING
34	7A191	GASKET — OIL PAN	83	7B164-EA	PLATE — OVERDRIVE CLUTCH PRESSURE
35	7G186-AA	FILTER AND SEAL ASSEMBLY (4X2)	84	7B442-DA	PLATE — OVERDRIVE CLUTCH INTERNAL SPLINE
36	7G186-BA	FILTER AND SEAL ASSEMBLY (4X4)	85	N804948-S	RING — RETURN SPRING RETAINING
37	N805327-S	NUT (5 PCS) M6X1.0	86	7G418	SPRING — OVERDRIVE RETURN
38	7A264-FA	BOLT (7 PCS) M6X1.0X66MM	87	7A548	PISTON — OVERDRIVE
39	7A264-GA	PAN — OIL (4X2)	88	7F225	SEAL — OVERDRIVE OUTER
40	N605902-S36	BOLT — OIL PAN (20 PCS) M8X1.25X12MM	89	7B421	SEAL — OVERDRIVE INNER (SAME AS INTERMEDIATE INNER)
41	7902	TORQUE CONVERTER ASSEMBLY	90	7G385	RING — INT.O.D. CYLINDER RETAINING
42	87650-S2	— PLUG — CONVERTER DRAIN 1/8 IN-27	91	7F225	CYLINDER — INTERMEDIATE OVERDRIVE
43	7017	SHAFT — INPUT	92	7E005	SEAL — INTERMEDIATE INNER
44	N805260-S	BOLT & WASHER ASSEMBLY — PUMP (9 PCS) M8X1.25X65MM	93	7F224	PISTON — INTERMEDIATE
45	7G379	— WASHER — REPLACEMENT (9 PCS)	94	7B070-DB	SEAL — INTERMEDIATE OUTER
46	7L323	SEAL RING — TEFLON	95	7G033	SPRING — INTERMEDIATE RETURN
47	7A248	SEAL — CONVERTER HUB	96	7L326	SUPPORT ASSEMBLY — CENTER
48	7D441	SEAL — SQUARE CUT O.D. PUMP	97	7D429-A	WASHER — THRUST
49	7A103	PUMP ASSEMBLY	98	7B066-CA	SEAL — DIRECT CLUTCH CAST IRON (2 PCS)
50	7D014	WASHER — PUMP THRUST	99	7F219	PLATE — INTERMEDIATE CLUTCH APPLY
51	7E486	NEEDLE BEARING ASSEMBLY	100	7B442	PLATE — INTERMEDIATE CLUTCH INTERNAL SPLINE
52	7G402	SEAL RING — TEFLON (2 PCS)	101	7B437	PLATE — INTERMEDIATE CLUTCH EXTERNAL SPLINE
53	7A136	GASKET — PUMP	102	N805310-S101	BOLT — INTERMEDIATE CLUTCH PRESSURE
54	7N463	STUB TUBE	103	N805311-S101	BOLT — CYLINDER HYDRAULIC FEED (1 PC.) M10X1.5X24MM
55	7L027	MAGNET — PAN	104	7D034	(2 PCS) CENTER SUPPORT HYDRAULIC FEED
56	7N171	PLUG — CONVERTER ACCESS	105	7D028	BAND ASSEMBLY
57	N605770-S36	BOLT — HEAT SHIELD (2 PCS)	106	7E221	SPRING — SERVO RETURN
58	7A434	HEAT SHIELD — SOLENOID BODY CONNECTOR	107		PISTON ASSEMBLY — SERVO

\* NOT SERVICED  
\* SERVICED IN KITS ONLY



# Technical Service Information

## E4OD EXPLODED VIEW LEGEND (CONTINUED)

100.	7D027	PLATE — SERVO COVER	142.	377300-S	RING — RETAINING	
101.	N660246-S	RING — SERVO RETAINING	143.	N805207-S	RING — RETAINING	
102.	7G380	RACE — INTERMEDIATE ONE WAY CLUTCH OUTER	144.	7D408	PLATE — REVERSE CLUTCH PRESSURE	
103.	7F271	CLUTCH ASSEMBLY — INTERMEDIATE	145.	7B442-EA	PLATE — REVERSE CLUTCH EXTERNAL SPLINE	
		ONE WAY	146.	7E312	PLATE — REVERSE CLUTCH INTERNAL SPLINE	
104.	7G401	WASHER — THRUST (L.G. DIA.)	147.	377155-S	RING — RETAINING	
105.	7D044	DRUM ASSY. — INTERMEDIATE BRAKE	148.	7D423	WASHER — THRUST	
106.	7A548-CA	SEAL — INNER	149.	7D006	CARRIER ASSEMBLY — REVERSE PLANETARY	
107.	7A548-FA	SEAL — OUTER		7D007	CARRIER	
108.	7A262	PISTON ASSEMBLY		7D008-BB	PLANET GEARS (4 PCS.)	
#	7A258	— PISTON		#	7A238-BA	PLANET SHAFTS (4 PCS.)
#	375393-S	— CHECK BALL (7/32 INCH DIA.)		#	7A242-BA	THRUST WASHERS (8 PCS.)
#	7E220	— BALL RETAINER		#	7D037-CA	NEEDLE BEARINGS (84 PCS.)
109.	7G298	SPRING — PISTON RETURN		#	380225-S	RETAINING PINS (4 PCS.)
110.	N804817-S	RING — SPRING RETAINING	150.	7D423	WASHER — THRUST	
111.	7D428	WASHER — THRUST (SMALL DIA.)	151.	387031-S	RING — RETAINING (FOR OUTPUT SHAFT)	
112.	7B164-GA	PLATE — DIRECT CLUTCH INTERNAL SPLINE	152.	7A153	GEAR — REVERSE RING	
113.	7B442-FA	PLATE — DIRECT CLUTCH EXTERNAL SPLINE	153.	7D164	HUB — OUTPUT SHAFT	
114.	7B066-BA	PLATE — DIRECT CLUTCH PRESSURE	154.	377132-S	RING — RETAINING	
115.	377126-S	RING — RETAINING (SELECTIVE FIT)	155.	E7AP-7E193-AA	REVERSE HUB AND CLUTCH ASSY (4X2)	
	377127-S	RING — RETAINING		E7TP-7E193-AA	REVERSE HUB AND CLUTCH ASSY (4X4)	
	377128-S	RING — RETAINING	#	E7AP-7D390-AA	HUB ASSEMBLY (4X2)	
	377437-S	RING — RETAINING	#	E7TP-7D390-AA	HUB ASSEMBLY (4X4)	
	377444-S	RING — RETAINING	#	7E392	SPRING ASSEMBLY	
116.	7D019	SEAL RING — TEFLON (2 PCS.)	#	7190	ROLLER — OVERRUNNING CLUTCH	
117.	7F374	NEEDLE BEARING ASSEMBLY	#	377135-S	RING — RETAINING (2 PCS.)	
118.	7D424	CYLINDER — FORWARD CLUTCH ASSEMBLY	#	7E194	BUSHING — OVERRUNNING CLUTCH	
119.	7E244	SEAL — INNER	156.	7E413	NEEDLE BEARING ASSEMBLY	
120.	7A548	SEAL — OUTER	157.	7D171	RACE — LOW/REVERSE ONE WAY CLUTCH INNER	
121.	7A262	PISTON ASSEMBLY	158.	7F153	SPRING — PISTON RETURN	
#	7A258	— PISTON	159.	7D404	SEAL — INNER	
#	375393-S	— CHECK BALL	160.	7D403	SEAL — OUTER	
#	7E220	— BALL RETAINER	161.	7D402	PISTON	
122.	7D256	RING — PISTON APPLY	162.	7D167	BOLTS (5 PCS.) 5/16 IN-24 (ONE WAY CLUTCH TO CASE)	
123.	7B070-AA	SPRING — PISTON RETURN	163.	7B368	WASHER — THRUST	
124.	377127-S	RING — RETAINING (FOR RETURN SPRING)	164.	7A233	PARKING GEAR	
125.	7B066-AA	PLATE — FORWARD CLUTCH PRESSURE	165.	7D60-AA	OUTPUT SHAFT ASSEMBLY (4X2)	
126.	7E457	SPRING — CUSHION	165A.	7D60-CA	OUTPUT SHAFT ASSEMBLY (4X4)	
127.	7B442-FA	PLATE — FORWARD CLUTCH EXTERNAL SPLINE	166.	387035-S	RING — RETAINING (1-9/16 IN DIA.)	
128.	7E311-AA	PLATE — FORWARD CLUTCH INTERNAL SPLINE	167.	7D070	SPRING — PARKING PAWL RETURN	
129.	7B066-BA	PLATE — FORWARD CLUTCH PRESSURE	168.	387640-S	PIN — PARKING PAWL	
130.	377127-S	RING — RETAINING (SELECTIVE FIT)	169.	7A441	PARKING PAWL	
	377437-S	RING — RETAINING	170.	N805232-S	BOLT AND WASHER ASSEMBLY (2 PCS.)	
	377444-S	RING — RETAINING	171.	7D419	PLATE — PARKING ROD GUIDE	
	386841-S	RING — RETAINING	172.	N805261-S190	BOLT (1 PC.)	
	386842-S	RING — RETAINING	173.	7G101	ABUTMENT — PARKING PAWL ACTUATING	
131.	7D090	WASHER — PLASTIC THRUST	174.	7A256	LEVER ASSEMBLY — MANUAL CONTROL	
			174A.	7341	INSULATOR	
132.	377132-S	RING — RETAINING	175.	7B210	PIN — MANUAL LEVER RETAINING	
133.	7D393	HUB — FORWARD	176.	7A115	LEVER — INNER DETENT	
134.	7D392	GEAR — FORWARD RING	177.	N800287-S36	NUT — INNER DETENT LEVER M14X1.5 HEX	
135.	7F078	NEEDLE BEARING ASSEMBLY	178.	7E332	SPRING ASSEMBLY — MANUAL VALVE DETENT	
136.	7D423	WASHER — THRUST	179.	N805503-S	BOLT — HEX FLANGE HEAD M6X1.0X16.5MM	
137.	7A398	CARRIER ASSEMBLY — FORWARD PLANETARY	180.	7D410	ROD ASSEMBLY — PARKING PAWL ACTUATING	
#	7D055	— CARRIER	181.	87034-94	O-RING FILLER TUBE	
#	7D008-AB	PLANET GEARS (4 PCS.)	182.	7A228	TUBE ASSY. — OIL FILLER	
#	7A238-AA	PLANET SHAFTS (4 PCS.)	183.	7A020	INDICATOR ASSY. — OIL LEVEL	
#	7A242-AA	THRUST WASHERS (8 PCS.)				
#	7D037-CA	NEEDLE BEARINGS (68 PCS.)				
#	380225-S	RETAINING PINS (4 PCS.)				
138.	7F078	NEEDLE BEARING ASSEMBLY				
139.	7D063	GEAR — FORWARD/REVERSE SUN ASSEMBLY				
140.	7D064	INPUT SHELL				
141.	7D066	WASHER — THRUST				

\*NOT SERVICED

\*SERVICED IN KITS ONLY

\*NOT SERVICED  
\*SERVICED IN KITS ONLY





## Diagnosis and Testing

### Shift Point Tests

This test verifies that the shift control system is operating properly.

#### Road Test

1. Bring engine transmission up to normal operating temperature.
2. Operate the vehicle with the transmission selector in  $\odot$  range.
3. Apply minimum throttle pressure and observe the upshift speeds and speeds at which the converter and clutch apply. Refer to Technical Service Bulletin Special Specifications issue.
4. With vehicle in overdrive (fourth gear), depress overdrive cancel switch. Transmission should downshift into third gear.
5. Depress accelerator pedal to the floor (WOT). Transmission should shift from third to second, or third to first depending on vehicle speed and converter clutch should release and then reapply.
6. With vehicle in  $\odot$  range above 80 km/h (50 mph) and less than half throttle, move transmission selector from  $\odot$  range to 2 range and remove foot from accelerator pedal. Transmission should immediately downshift into second gear. With vehicle remaining in 2 range, move transmission selector into 1 range, and release accelerator pedal. Transmission should downshift into first gear at speeds below 48-56 Km/h (30-35 mph).
7. If transmission fails to upshift and/or downshift as outlined, refer to Diagnostic Charts Section.

### In-Shop Test

1. Raise rear of vehicle so that rear wheels are clear of floor.

**CAUTION: Do not exceed 97 Km/h (60 mph) indicated speedometer speed. Do not exceed recommended tire speed rating.**

2. To check shift valves, place selector lever in  $\odot$  range. Apply throttle pressure and observe upshift speeds.

At the shift points, the speedometer needle will make a momentary surge, a slight driveline bump may be felt and engine speed will drop without releasing accelerator pedal.

3. If transmission fails to upshift and/or downshift as outlined, refer to Diagnostic Charts in this Section.

### Air Pressure Checks

A NO DRIVE condition can exist, even with correct transmission fluid pressure, because of inoperative clutches or bands. An erratic shift can be located through a series of checks by substituting air pressure for fluid pressure to determine the location of the malfunction.

When the selector lever is in a forward gear range ( $\odot$ , 2 and 1) a NO DRIVE condition may be caused by an inoperative forward clutch, overdrive one-way clutch or low/reverse one-way clutch.

No manual low (1) coast could be caused by an inoperative coast clutch or reverse clutch.


Failure to drive in R (REVERSE) could be caused by a malfunction of the reverse clutch, overdrive one-way clutch or direct clutch.

1. Drain transmission fluid and remove oil pan.
2. Remove filter and seal assembly, solenoid body and the main control assemblies.

## DIAGNOSIS AND TESTING (Continued)

3. The inoperative clutches can be located by introducing air pressure into the various test passages as follows:

### Air Pressure Check Locations



### Clutches: Forward, Coast, Reverse, Overdrive, Direct and Intermediate

Apply air pressure to appropriate clutch test port. A dull thud can be heard, or movement of piston felt when clutch piston is applied. If clutch seal(s) are leaking, a hissing sound will be heard.

### Clutch Band Application Chart

Gear	Friction Elements							One-Way Clutch					
	Coast	Inter-mediate	Direct	Forward	Reverse	Over-Drive	Band	Drive			Coast		
								O/D OWC	Inter-mediate OWC	Low Reverse OWC	O/D OWC	Inter-mediate OWC	Low Reverse OWC
	①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬
Ⓐ first	•			apply				hold		hold	o/r*		o/r
Ⓑ second	•	apply		apply				hold	hold	o/r	o/r*	o/r	o/r
Ⓒ third	•	apply	apply	apply				hold	o/r	o/r	o/r*	o/r	o/r
Ⓓ fourth		apply	apply	apply		apply		o/r	o/r	o/r	o/r	o/r	o/r
1	apply			apply	apply								
2	apply	apply		apply			apply			o/r			o/r
Reverse	apply		apply		apply				o/r			o/r	

O/D — Overdrive

OWC — One-Way Clutch

O/R — Overrunning

\*In D Range with the Overdrive Cancel Switch pressed, the coast clutch is applied and the O/D one-way clutch is bypassed.



## Technical Service Information

# QUICK TEST: VISUAL CHECK / VEHICLE PREPARATION

### SPECIAL NOTES

- Correct results of the QUICK TEST are dependent on the proper operation of related non-EEC-IV components.
- It may be necessary to disconnect or disassemble the harness connector assemblies to do some of the inspections. Pin locations should be noted before disassembly.
- If the engine will not start, starts but stalls, idles rough, or runs rough; continue through QUICK TEST (KOEO SELF TEST on page 13

### VISUAL CHECK

1. Inspect the air cleaner and inlet ducting.
2. Check all engine vacuum hoses for damage, leaks, cracks, blockage, proper routing, etc.
3. Check EEC-IV system wiring harness for proper connections, bent or broken pins, corrosion loose wires, proper routing, etc.
4. Check the processor, sensors and actuators for physical damage.
5. Check the engine coolant for proper level.
6. Check transmission fluid level and quality.
7. Make all necessary repairs before continuing with QUICK TEST.

### VEHICLE PREPARATION

1. Perform ALL safety steps required to start and run vehicle - apply parking brake, place shift lever firmly into the PARK position, and block the drive wheels, etc.
2. Turn off ALL electrical loads - radios, lights, AC, etc.
3. Start engine and run it up to operating temperature.
4. Turn engine off and proceed to QUICK TEST HOOK-UP on page 12.

# Technical Service Information


## QUICK TEST: EQUIPMENT HOOK-UP

### SPECIAL NOTES:

- Refer to the illustrations for self test connector pin orientation and VOM and STAR hook up.
- After the equipment is properly hooked up, proceed to QUICK TEST KOEO TEST on page 13.

### USING THE STAR TESTER

1. Turn the ignition key off.
2. Set the VOM on a DC voltage range to read from 0 to 15 volts.
3. Connect the adapter cable leads to the proper Self-Test connectors.
4. Connect the timing light.



### USING AN ANALOG VOLT/OHM METER (VOM)

1. Turn the ignition key off.
2. Set the VOM on a DC voltage range to read from 0 to 15 volts.
3. Connect the VOM from the battery + terminal to the Self-Test Output pin of the large Self-Test connector.
4. Connect the timing light.



## QUICK TEST: KEY ON ENGINE OFF TEST

### SPECIAL NOTES:

- It may be necessary to service non-EEC-IV faults before running Quick Test.
- Continuous Memory Codes recorded in this step will be used for diagnosis in QUICK TEST SERVICE CODES (on page 26) after a pass code 11 is received in both the Key On Engine Off And The Engine Running Self-test.
- Deviation from this procedure may cause the output of false codes.
- On all vehicles equipped with a 2.5L OR 4.9L ENGINE, the clutch must be depressed during the KOEO Self Test. In vehicles equipped with a 7.3L diesel engine, The throttle must be depressed (WOT) during the entire KOEO Self Test.

### HOW TO RUN THE KEY ON ENGINE OFF SELF TEST

#### DO

- Verify that the vehicle has been properly prepared according to QUICK TEST STEPS on pages 12 and 13.
- Place ignition key in the ON position.
- For 7.3 Diesel vehicles only, depress the throttle.
- Activate Self Test.

STAR TESTER: Latch the center button in the down position.

Analog VOM: Jumper STI to SIG RTN at the Self Test connectors.

"Check Engine" light (MIL): Jumper STI to SIG RET at the Self Test connectors.  
Service Codes will be flashed on the "Check Engine" light.

- Record all service codes.

#### DON'T

- Depress throttle during KOEO Self Test on gasoline engine applications.
- Activate Self Test before turning key to on position.

## READING CODES WITH THE "CHECK ENGINE" LIGHT

### READING CODES — "CHECK ENGINE" LIGHT (MIL)

During Self-Test a service code is reported by the "Check Engine" Light. It will represent itself as a flash on the "Check Engine" Light display on the dash panel (Figure 7). A single-digit number of three will be reported by three flashes.

However, as previously stated, a service code is represented by a two-digit number, such as 2-3. As a result, the Self-Test service code of 2-3 will appear on the "Check Engine" Light display as two flashes, then, after a two-second pause, the light will flash three times.

The Continuous Memory Codes are separated from the Key On Engine Off codes by a six-second delay, a single half-second flash, and another six-second delay. They are produced on the "Check Engine" Light display in the same manner as the Key On Engine Off codes.




Figure 7 "Check Engine" Light Output Code Format





## Technical Service Information

### DIAGNOSIS GUIDE — E4OD

CONDITION	POSSIBLE SOURCE	ACTION
Fluid Leaks	<ol style="list-style-type: none"><li>1. Case breather valve — Transmission fluid foaming</li><li>2. Leakage at gasket, seals etc.</li></ol>	<ol style="list-style-type: none"><li>1. Refer to service procedure in Mechanical Diagnostics in this section. Service as required.</li><li>2. Refer to General Diagnostics at the beginning of this section.</li></ol>
Fluid venting or foaming	<ol style="list-style-type: none"><li>1. Check fluid level (venting) — Transmission overfilled</li><li>2. Inspect transmission fluid — Contaminated with anti-freeze or engine overheating</li><li>3. Inspect transmission fluid filter — Damaged seal — Misassembly to pump</li></ol>	<ol style="list-style-type: none"><li>1. Drain transmission to proper level.</li><li>2. Determine source of leak. Service as required.</li><li>3. Replace filter seals or reassemble fluid filter.</li></ol>
Stalls when stopping	<ol style="list-style-type: none"><li>1. Poor engine performance</li><li>2. Check fluid level</li><li>3. Check electronic engine control operation</li><li>4. Test converter clutch — Converter clutch does not release</li></ol>	<ol style="list-style-type: none"><li>1. Check engine and service as required.</li><li>2. Drain or fill transmission to proper level.</li><li>3. Refer to Quick Test</li><li>4. Refer to service procedure in this section.</li></ol>
Shift efforts high	<ol style="list-style-type: none"><li>1. Inspect manual shift linkage — Damaged or misadjusted</li><li>2. Inspect manual lever retainer pin — Damaged</li><li>3. Check detent spring</li><li>4. Inspect inner manual lever nut</li></ol>	<ol style="list-style-type: none"><li>1. Service as required. Refer to Removal and Installation in this section.</li><li>2. Adjust linkage and install new pin.</li><li>3. Service as required.</li><li>4. Tighten nut to specification listed at the end of this section.</li></ol>
Poor vehicle performance	<ol style="list-style-type: none"><li>1. Poor engine performance</li><li>2. Test converter clutch — Converter clutch does not release</li><li>3. Inspect torque converter one-way clutch — One-way clutch locked up</li></ol>	<ol style="list-style-type: none"><li>1. Perform Quick Test Section</li><li>2. Refer to service procedure in this section.</li><li>3. Replace converter.</li></ol>
Vehicle will not start	<ol style="list-style-type: none"><li>1. Inspect ignition switch — Misadjusted or defective</li><li>2. Check fluid level — Fluid level high or low</li><li>3. Check electronic engine control operation</li></ol>	<ol style="list-style-type: none"><li>1. Adjust or replace as required.</li><li>2. Drain or fill transmission to proper level.</li><li>3. Refer to Quick Test Section</li></ol>

### AUTOMATIC TRANSMISSION SERVICE GROUP



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
Transmission overheats	<ol style="list-style-type: none"><li>Excessive tow loads</li><li>Check fluid level — Fluid level high or low</li><li>Check electronic engine control operation</li><li>Inspect transmission cooler and cooler lines — Restricted or blocked</li><li>Test converter clutch — Converter clutch does not apply</li><li>Inspect valve body — Dirty or sticky valves</li><li>Inspect torque converter one-way clutch — One-way clutch locked up</li></ol>	<ol style="list-style-type: none"><li>Check owner's manual for tow restriction.</li><li>Drain or fill transmission to proper level.</li><li>Refer to Quick Test Section</li><li>Service as required. Refer to General Diagnosis in the beginning of this section.</li><li>Refer to service procedure in this section.</li><li>Clean, service or replace valve body.</li><li>Refer to General Diagnosis in the beginning of this section. Replace the converter if necessary.</li></ol>
No 1st gear, starts in higher gear	<ol style="list-style-type: none"><li>Check line pressure — Low line pressure</li><li>Check solenoid operation</li><li>Inspect D2 valve, 2-3 shift valve and 3-4 shift valve — Springs missing or tangled — Dirty or sticky valve</li></ol>	<ol style="list-style-type: none"><li>Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>Refer to electrical diagnosis procedure in this section. Service as required.</li><li>Determine source of contamination or damage. Service as required.</li></ol>
No 1-2 upshift	<ol style="list-style-type: none"><li>Check fluid level — Fluid level high or low</li><li>Check manual linkage — Misadjusted/damaged</li><li>Test line pressure — Low to intermediate friction clutch</li><li>Check solenoid operation — (S2 solenoid suspected)</li><li>Inspect valve body bolts — Bolts loose or tight</li><li>Inspect valve body — Dirty/sticky valves</li><li>Inspect 1-2 shift valve — Stuck, nicked or damaged</li><li>Inspect D2 valve — Spring missing or damaged — Dirty or sticky valve</li></ol>	<ol style="list-style-type: none"><li>Drain or fill transmission to the proper level.</li><li>Service as required. Refer to Adjustments at the beginning of this section.</li><li>Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>Refer to electrical diagnosis procedure in this section. Service as required.</li><li>Tighten bolts to specification.</li><li>Determine source of contamination. Service as required.</li><li>Determine source of contamination. Service as required.</li><li>Determine source of contamination. Service as required.</li></ol>

AUTOMATIC TRANSMISSION SERVICE GROUP



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No 1-2 upshift (Cont'd)	<ul style="list-style-type: none"><li>9. Inspect intermediate clutch accumulator regulator valve<ul style="list-style-type: none"><li>— Stuck, nicked or damaged</li></ul></li><li>10. Inspect intermediate clutch accumulator<ul style="list-style-type: none"><li>— Plunger stuck or damaged</li><li>— Springs missing or damaged</li></ul></li><li>11. Inspect intermediate clutch assembly<ul style="list-style-type: none"><li>— Clutch plates damaged/missing</li><li>— Piston or seals damaged</li><li>— Ball check stuck/missing</li><li>— Feedbolt loose/missing/sealant leak</li><li>— Clutch hub damaged</li></ul></li><li>12. Inspect intermediate one-way clutch assembly<ul style="list-style-type: none"><li>— Damaged cage/sprags</li><li>— Misassembled on inner race</li></ul></li></ul>	<ul style="list-style-type: none"><li>9. Determine source of contamination. Service as required.</li><li>10. Determine source of contamination. Service as required.</li><li>11. Determine source of contamination or damage. Service as required.</li><li>12. Disassemble and inspect. Service as required.</li></ul>
1-2 Shift harsh or soft	<ul style="list-style-type: none"><li>1. Check line pressure<ul style="list-style-type: none"><li>— High or low line pressure</li></ul></li><li>2. Service line modulator pressure<ul style="list-style-type: none"><li>— High or low</li></ul></li><li>3. Inspect valve body bolts<ul style="list-style-type: none"><li>— Loose or tight</li></ul></li><li>4. Inspect intermediate clutch accumulator regulator valve<ul style="list-style-type: none"><li>— Valve stuck, nicked or damaged</li><li>— Spring missing or tangled</li></ul></li><li>5. Inspect valve body<ul style="list-style-type: none"><li>— Dirty or sticky valves</li></ul></li><li>6. Inspect intermediate clutch accumulator<ul style="list-style-type: none"><li>— Plunger stuck or damaged</li><li>— Springs missing or tangled</li></ul></li></ul>	<ul style="list-style-type: none"><li>1. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>2. Refer to service procedure in this section if necessary.</li><li>3. Tighten bolts to the specification listed at the back of this section.</li><li>4. Determine source of contamination or damage. Service as required.</li><li>5. Determine source of contamination. Service as required.</li><li>6. Determine source of contamination or damage. Service as required.</li></ul>
2-3 Shift harsh or soft	<ul style="list-style-type: none"><li>1. Check line pressure<ul style="list-style-type: none"><li>— High or low line pressure</li></ul></li><li>2. Service line modulator pressure<ul style="list-style-type: none"><li>— High or low</li></ul></li><li>3. Inspect valve body bolts<ul style="list-style-type: none"><li>— Loose or tight</li></ul></li><li>4. Inspect intermediate clutch accumulator regulator valve<ul style="list-style-type: none"><li>— Valve stuck, nicked or damaged</li><li>— Spring missing or tangled</li></ul></li></ul>	<ul style="list-style-type: none"><li>1. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>2. Refer to service procedure in this section if necessary.</li><li>3. Tighten bolts to the specification listed at the back of this section.</li><li>4. Determine source of contamination or damage. Service as required.</li></ul>



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
2-3 Shift harsh or soft (Cont'd)	<ul style="list-style-type: none"><li>5. Inspect intermediate clutch accumulator<ul style="list-style-type: none"><li>— Plunger stuck or damaged</li><li>— Springs missing or tangled</li></ul></li><li>6. Inspect valve body<ul style="list-style-type: none"><li>— Dirty or sticky valves</li></ul></li><li>7. Inspect pump air bleed check valve<ul style="list-style-type: none"><li>— Valve leaking or damaged</li></ul></li><li>8. Inspect intermediate clutch assembly<ul style="list-style-type: none"><li>— Clutch plates damaged/missing</li><li>— Piston or seals damaged</li><li>— Ball check stuck or missing</li><li>— Feedbolt loose/missing sealant leak</li><li>— Clutch hub damaged</li></ul></li></ul>	<ul style="list-style-type: none"><li>5. Determine source of contamination or damage. Service as required.</li><li>6. Determine source of contamination. Service as required.</li><li>7. Determine source of contamination or damage. Service as required.</li><li>8. Determine source of contamination or damage. Service as required.</li></ul>
No 2-3 upshift	<ul style="list-style-type: none"><li>1. Check fluid level<ul style="list-style-type: none"><li>— Fluid level high or low</li></ul></li><li>2. Check line pressure<ul style="list-style-type: none"><li>— Low to direct clutch</li></ul></li><li>3. Check solenoid operation<ul style="list-style-type: none"><li>— (S1 solenoid suspected)</li></ul></li><li>4. Inspect valve body bolts<ul style="list-style-type: none"><li>— Loose or tight</li></ul></li><li>5. Inspect valve body<ul style="list-style-type: none"><li>— Dirty or sticky valves</li></ul></li><li>6. Inspect 2-3 shift valve<ul style="list-style-type: none"><li>— Valve stuck, nicked or damaged</li></ul></li><li>7. BS5 check ball missing<ul style="list-style-type: none"><li>— Plate seat damaged</li></ul></li><li>8. Inspect direct clutch assembly<ul style="list-style-type: none"><li>— Clutch plates damaged/missing</li><li>— Piston or seals damaged</li><li>— Ball check assembly stuck or missing</li></ul></li><li>9. Inspect direct clutch cylinder<ul style="list-style-type: none"><li>— Seals damaged or missing or holes blocked</li></ul></li><li>10. Inspect center support<ul style="list-style-type: none"><li>— Damaged</li><li>— Feedbolts loose or missing</li><li>— Center support O.D. or case bore damaged/leaking</li><li>— Teflon seal damaged</li></ul></li></ul>	<ul style="list-style-type: none"><li>1. Drain or fill transmission to the proper level.</li><li>2. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>3. Refer to electrical diagnosis procedure in this section. Service as required.</li><li>4. Tighten bolts to the specification listed at the back of this section.</li><li>5. Determine source of contamination. Service as required.</li><li>6. Determine source of contamination. Service as required.</li><li>7. Service as required.</li><li>8. Determine source of contamination. Service as required.</li><li>9. Determine source of contamination. Service as required.</li><li>10. Service as required.</li></ul>

AUTOMATIC TRANSMISSION SERVICE GROUP



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
2-3 Shift harsh or soft	<ol style="list-style-type: none"><li>1. Check line pressure — High or low line pressure</li><li>2. Service line modulator pressure — High or low</li><li>3. Inspect valve body bolts — Bolts tight or loose</li><li>4. Inspect valve body — Dirty or sticky valves</li><li>5. Inspect direct clutch accumulator regulator valve — Valve stuck, nicked or damaged — Spring missing or tangled</li><li>6. Inspect direct clutch accumulator — Springs missing or tangled — Plunger nicked or damaged</li><li>7. Inspect direct clutch assembly — Clutch plates damaged/missing — Piston or seals damaged — Ball check assembly stuck or missing</li><li>8. Inspect direct clutch cylinder — Seals damaged, missing or holes blocked</li><li>9. Inspect center support — Damaged — Feedbolts loose or missing — Center support O.D. or case bore damaged/leaking — Teflon seal damaged</li></ol>	<ol style="list-style-type: none"><li>1. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>2. Refer to service procedure in this section if necessary.</li><li>3. Tighten bolts to the specification listed at the back of this section</li><li>4. Determine source of contamination. Service as required.</li><li>5. Determine source of contamination or damage. Service as required.</li><li>6. Determine source of contamination. Service as required.</li><li>7. Determine source of contamination or damage. Service as required.</li><li>8. Determine source of contamination. Service as required.</li><li>9. Service as required.</li></ol>
No 3-4 upshift	<ol style="list-style-type: none"><li>1. Check fluid level — Fluid level high or low</li><li>2. Check line pressure — High or low line pressure</li><li>3. Check solenoid operation — (S2 solenoid suspected)</li><li>4. Inspect valve body bolts — Bolts tight or loose</li><li>5. Inspect valve body — Dirty or sticky valves</li><li>6. Inspect 3-4 shift valve — Valve stuck, nicked or damaged — Springs missing or tangled</li><li>7. Inspect overdrive accumulator regulator valve — Valve stuck, nicked or damaged — Spring missing or tangled</li></ol>	<ol style="list-style-type: none"><li>1. Drain or fill transmission to the proper level.</li><li>2. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>3. Refer to electrical diagnosis procedure in this section. Service as required.</li><li>4. Tighten bolts to the specification listed at the back of this section.</li><li>5. Determine source of contamination. Service as required.</li><li>6. Determine source of contamination. Service as required.</li><li>7. Determine source of contamination or damage. Service as required.</li></ol>

### AUTOMATIC TRANSMISSION SERVICE GROUP



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No 3-4 upshift (Cont'd)	8. Inspect overdrive clutch assembly — Clutch plates burnt or worn — Overdrive clutch cylinder damaged/feedbolt loose or missing/sealant leaking — Cylinder ball check assembly stuck or missing	8. Service as required.
3-4 Shift harsh or soft	1. Check line pressure — Line pressure high or low  2. Service line modulator pressure — High or low  3. Inspect valve body bolts — Bolts loose or tight  4. Inspect valve body — Dirty or sticky valves  5. Inspect overdrive accumulator regulator valve — Valve stuck, nicked/damaged — Spring missing or tangled  6. Inspect overdrive accumulator — Accumulator plunger stuck or damaged — Springs missing or tangled  7. Inspect overdrive clutch assembly — Clutch plates burnt or worn — Overdrive clutch cylinder damaged or feedbolt loose or missing — Cylinder ball check assembly stuck or missing	1. Perform line pressure test. Refer to service procedure in this section if necessary.  2. Refer to service procedure in this section if necessary.  3. Tighten bolts to the specification listed at the back of this section.  4. Determine source of contamination. Service as required.  5. Determine source of contamination. Service as required.  6. Determine source of contamination. Service as required.  7. Service as required.
Shifts 1-3	1. Check fluid level — Fluid level high or low  2. Check solenoid operation — (S1 solenoid suspected)  3. Inspect D2 shift valve — Dirty or sticky — Spring missing or damaged  4. Inspect intermediate clutch accumulator regulator valve — Valve sticky or dirty  5. Inspect intermediate friction clutch — Burnt or worn	1. Drain or fill transmission to the proper level.  2. Refer to electrical service procedure in this section. Service as required.  3. Determine source of contamination. Service as required.  4. Determine source of contamination. Service as required.  5. Service as required.





## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
Shifts 1-3 (Cont'd)	6. Inspect intermediate one-way clutch assembly — Damaged cage/sprags — Misassembled on inner race	6. Disassemble and inspect. Service as required.
Shift speed high or low	1. Check fluid level — Fluid level high or low  2. Check electronic engine control operation  3. Inspect vehicle speed sensor — Wrong gear/damaged gear	1. Drain or fill transmission to the proper level. 2. Refer to Quick Test Section  3. Repair or replace as necessary.
4-3 Downshift harsh	1. CB7 check ball missing — Plate seat damaged	1. Service as required.
3-2 Downshift harsh	1. CB6 check ball missing — Plate seat damaged	1. Service as required.
2-1 Downshift harsh	1. CB14 check ball missing — Plate seat damaged	1. Service as required.
No drive in drive range	1. Check fluid level — Fluid level low  2. Check line pressure — Line pressure low  3. Inspect manual linkage (internal and external) — Misadjusted, disconnected, damaged, broken or bent  4. Check transmission filter inside oil pan  5. Inspect valve body and pump control body bolts — Loose or tight  6. Inspect pump control body and valve body — Dirty or sticky valves  7. Inspect overdrive one-way clutch — Improperly assembled/damaged — Damaged sprags or races  8. Inspect forward clutch assembly — Burnt or missing clutch plates — Damaged piston or seals — Forward clutch ball check assembly missing or damaged — Center support seals damaged or missing/holes blocked/feedbolt loose or missing — Forward clutch hub damaged	1. Fill transmission to the proper level. 2. Perform line pressure test. Refer to service procedure in this section if necessary. 3. Service as required.  4. Replace filter if plugged.  5. Tighten bolts to the specification listed at the back of this section.  6. Determine source of contamination. Service as required. 7. Service as required.  8. Determine source of contamination or damage. Service as required.



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No drive in drive range (Cont'd)	<ul style="list-style-type: none"><li>9. Inspect reverse one-way clutch<ul style="list-style-type: none"><li>— Improperly assembled</li><li>— Damaged rollers</li></ul></li><li>10. Inspect front sun gear/shell<ul style="list-style-type: none"><li>— Damaged</li></ul></li><li>11. Inspect front and rear carrier<ul style="list-style-type: none"><li>— Damaged pinions/lugs to rear ring gear</li></ul></li><li>12. Inspect reverse ring gear<ul style="list-style-type: none"><li>— Damaged gears/lugs to forward carrier</li></ul></li><li>13. Inspect output shaft<ul style="list-style-type: none"><li>— Damaged splines</li></ul></li></ul>	<ul style="list-style-type: none"><li>9. Determine source of damage. Service as required.</li><li>10. Determine source of damage. Service as required.</li><li>11. Determine source of damage. Service as required.</li><li>12. Determine source of damage. Service as required.</li><li>13. Determine source of damage. Service as required.</li></ul>
No reverse	<ul style="list-style-type: none"><li>1. Check fluid level<ul style="list-style-type: none"><li>— Fluid level low</li></ul></li><li>2. Inspect manual linkage<ul style="list-style-type: none"><li>— Misadjusted, disconnected, damaged, broken or bent</li></ul></li><li>3. Check line pressure<ul style="list-style-type: none"><li>— Line pressure low</li></ul></li><li>4. Check transmission filter inside oil pan</li><li>5. Inspect valve body and pump control body bolts<ul style="list-style-type: none"><li>— Loose or tight</li></ul></li><li>6. Inspect pump control body and valve body<ul style="list-style-type: none"><li>— Dirty or sticky valves</li></ul></li><li>7. Inspect direct clutch accumulator regulator valve<ul style="list-style-type: none"><li>— Valve stuck, nicked/damaged</li><li>— Spring missing or tangled</li></ul></li><li>8. BS5 checkball missing<ul style="list-style-type: none"><li>— Plate seat damaged</li></ul></li><li>9. Inspect direct clutch assembly (if 3rd gear inoperative)<ul style="list-style-type: none"><li>— Damaged piston or seals</li><li>— Burnt or missing clutch plates</li><li>— Direct clutch ball check assembly missing or damaged</li><li>— Center support seals damaged or missing or holes blocked</li><li>— Direct clutch hub damaged</li></ul></li><li>10. Inspect coast clutch assembly for leakage</li></ul>	<ul style="list-style-type: none"><li>1. Fill transmission to the proper level.</li><li>2. Service as required.</li><li>3. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>4. Replace filter if plugged.</li><li>5. Tighten bolts to the specification listed at the back of this section.</li><li>6. Determine source of contamination. Service as required.</li><li>7. Determine source of contamination or damage. Service as required.</li><li>8. Service as required.</li><li>9. Disassemble and inspect clutch assembly. Service as required.</li><li>10. Disassemble and inspect clutch assembly. Service as required.</li></ul>



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No reverse (Cont'd)	<ul style="list-style-type: none"><li>11. Inspect reverse clutch<ul style="list-style-type: none"><li>— Burnt or missing clutch plates</li><li>— Damaged piston or seals</li></ul></li><li>12. Inspect front and rear carrier<ul style="list-style-type: none"><li>— Damaged pinions/lugs to rear ring gear</li></ul></li></ul>	<ul style="list-style-type: none"><li>11. Determine source of damage. Service as required.</li><li>12. Determine source of damage. Service as required.</li></ul>
No park range	<ul style="list-style-type: none"><li>1. Inspect manual shift linkage<ul style="list-style-type: none"><li>— Damaged or misadjusted</li></ul></li><li>2. Damage park mechanism<ul style="list-style-type: none"><li>— Chipped or broken parking pawl or parking gear</li><li>— Broken park pawl return spring</li><li>— Bent or broken actuating rod</li></ul></li></ul>	<ul style="list-style-type: none"><li>1. Service as required. Refer to Adjustments at the beginning of this section.</li><li>2. Determine source of damage. Service as required.</li></ul>
Harsh neutral to drive or neutral to reverse engagements	<ul style="list-style-type: none"><li>1. Check fluid level<ul style="list-style-type: none"><li>— Fluid level low</li></ul></li><li>2. Check electronic engine control operation</li><li>3. Worm/damaged/loose U-joint, slip yoke, rear axle or rear suspension</li><li>4. Inspect valve body bolts<ul style="list-style-type: none"><li>— Loose or tight</li></ul></li><li>5. Engagement control valve<ul style="list-style-type: none"><li>— Valve stuck, nicked or damaged</li></ul></li><li>6. CB13 check ball missing<ul style="list-style-type: none"><li>— Plate seat damaged</li></ul></li><li>7. Inspect direct clutch accumulator regulator valves<ul style="list-style-type: none"><li>— Valve sticking or dirty</li><li>— Spring missing or tangled</li></ul></li><li>8. Inspect direct clutch accumulator<ul style="list-style-type: none"><li>— Accumulator plunger stuck</li><li>— Accumulator seal damaged or missing</li><li>— Springs missing or tangled</li></ul></li><li>9. Inspect forward clutch assembly<ul style="list-style-type: none"><li>— Burnt or missing clutch plates</li><li>— Damaged piston or seals</li><li>— Forward clutch ball check assembly missing or damaged</li><li>— Center support seals damaged or missing/holes blocked/feedbolt loose or missing</li><li>— Forward clutch hub damaged</li></ul></li><li>10. Inspect reverse clutch for leakage.</li><li>11. Excessive transmission end play</li></ul>	<ul style="list-style-type: none"><li>1. Fill transmission to the proper level.</li><li>2. Refer to Quick Test Section</li><li>3. Service as required.</li><li>4. Tighten bolts to specification.</li><li>5. Determine source of contamination. Service as required.</li><li>6. Service as required.</li><li>7. Determine source of contamination. Service as required.</li><li>8. Determine source of contamination. Service as required.</li><li>9. Determine source of contamination or damage. Service as required.</li><li>10. Identify source of leakage. Service as required.</li><li>11. Check transmission end play. Replace selective thrust washer if necessary.</li></ul>



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No forced downshifts	<ol style="list-style-type: none"><li>1. Check fluid level — Fluid level high or low</li><li>2. Check electronic engine control operation</li><li>3. Inspect valve body bolts — Bolts loose or tight</li><li>4. Inspect valve body — Dirty or sticky valves</li></ol>	<ol style="list-style-type: none"><li>1. Drain or fill transmission to the proper level.</li><li>2. Refer to Quick Test Section</li><li>3. Tighten bolts to the specification listed in the back of this section.</li><li>4. Determine source of contamination. Service as required.</li></ol>
No engine braking in manual one	<ol style="list-style-type: none"><li>1. Check fluid level — Fluid level low</li><li>2. Check line pressure — Line pressure low</li><li>3. Check solenoid operation — (S1 solenoid suspected)</li><li>4. Inspect for dirty or sticky valves — Reverse clutch modulator, D2 4-3-2 timing or 2-3 or coast clutch shift valves</li><li>5. Check ball missing — BS1, BS3 or CB1 — Plate seat damaged</li><li>6. Inspect coast clutch — Worn or burnt — Piston or seals damaged — Stator support damaged or holes blocked — Coast clutch hub damaged or holes blocked</li><li>7. Inspect reverse clutch — Worn or burnt — Piston or seals damaged</li></ol>	<ol style="list-style-type: none"><li>1. Fill transmission to the proper level.</li><li>2. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>3. Refer to electrical diagnosis procedure in this section.</li><li>4. Determine source of contamination. Service as required.</li><li>5. Service as required.</li><li>6. Service as required.</li><li>7. Service as required.</li></ol>
No engine braking in manual second	<ol style="list-style-type: none"><li>1. Check fluid level — Fluid level low</li><li>2. Check line pressure — Line pressure low</li><li>3. Inspect for dirty or sticky valves — 4-3-2 timing, D2, 2-3 or coast clutch shift valve</li><li>4. Check ball missing — BS1, BS3 or CB1 — Plate seat damaged</li><li>5. Check intermediate servo</li><li>6. Inspect intermediate band or drum — Worn or burnt</li></ol>	<ol style="list-style-type: none"><li>1. Fill transmission to the proper level.</li><li>2. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>3. Determine source of contamination. Service as required.</li><li>4. Service as required.</li><li>5. Perform air pressure test of servo for leakage. Service as required.</li><li>6. Service as required.</li></ol>



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
No engine braking in manual second (Cont'd)	7. Inspect coast clutch <ul style="list-style-type: none"><li>— Worn or burnt</li><li>— Piston or seals damaged</li><li>— Stator support damaged or holes blocked</li><li>— Coast clutch hub damaged or holes blocked</li></ul>	7. Service as required.
Erratic shifts	1. Check fluid level <ul style="list-style-type: none"><li>— Fluid level high or low</li></ul> 2. Check electronic engine control operation  3. Inspect vehicle speed sensor <ul style="list-style-type: none"><li>— Damaged or defective</li></ul> 4. Inspect valve body bolts <ul style="list-style-type: none"><li>— Bolts loose or tight</li></ul> 5. Inspect valve body <ul style="list-style-type: none"><li>— Dirty or sticky valves</li></ul>	1. Drain or fill transmission to the proper level. 2. Refer to Quick Test Section  3. Service as required.  4. Tighten bolts to the specification listed at the back of this section. 5. Determine source of contamination. Service as required.
Shift hunting	1. Check fluid level <ul style="list-style-type: none"><li>— Fluid level high or low</li></ul> 2. Check electronic engine control operation	1. Drain or fill transmission to the proper level. 2. Refer to Quick Test Section
High or low line pressure	1. Check fluid level <ul style="list-style-type: none"><li>— Fluid level high or low</li></ul> 2. Electronic pressure control solenoid malfunction  3. Main regulator valve or spring <ul style="list-style-type: none"><li>— Dirty or sticky valve</li><li>— Damaged spring</li></ul> 4. Pump assembly <ul style="list-style-type: none"><li>— Gears damaged, broken or worn</li></ul>	1. Drain or fill transmission to the proper level. 2. Refer to electrical diagnosis procedure in this section. Service as required. 3. Determine source of damage or contamination. Service as required. 4. Determine source of damage. Service as required.
No converter clutch apply	1. Check fluid level <ul style="list-style-type: none"><li>— Fluid level high or low</li></ul> 2. Electrical system or electronic engine control <ul style="list-style-type: none"><li>— No lock-up signal</li><li>— S3 solenoid malfunction</li><li>— Bulkhead connector damaged</li><li>— Pinched wires</li></ul> 3. Inspect stator shaft Teflon seal <ul style="list-style-type: none"><li>— Damaged seal</li></ul> 4. Converter clutch control valve <ul style="list-style-type: none"><li>— Dirty or sticky</li></ul>	1. Drain or fill transmission to the proper level. 2. Refer to electrical diagnosis procedure in this section. Service as required.  3. Determine source of contamination. Service as required. 4. Determine source of contamination. Service as required.



## Technical Service Information

### DIAGNOSIS GUIDE — E4OD (Cont'd)

CONDITION	POSSIBLE SOURCE	ACTION
Converter clutch does not release	<ol style="list-style-type: none"><li>1. Check fluid level — Fluid level high or low</li><li>2. Electrical system or electronic engine control — No unlock signal — S3 solenoid malfunction — Bulkhead connector damaged — Pinched wires</li><li>3. Converter clutch control valve — Dirty or stuck valve</li></ol>	<ol style="list-style-type: none"><li>1. Drain or fill transmission to the proper level.</li><li>2. Refer to electrical diagnosis procedure in this section. Service as required.</li><li>3. Determine source of contamination. Service as required.</li></ol>
Line modulator pressure high or low	<ol style="list-style-type: none"><li>1. Check line pressure — High or low line pressure</li><li>2. Inspect line pressure modulator valve — Valve stuck or damaged — Plunger or sleeve stuck or damaged</li></ol>	<ol style="list-style-type: none"><li>2. Perform line pressure test. Refer to service procedure in this section if necessary.</li><li>2. Determine source of contamination or damage. Service as required.</li></ol>

#### Electrical Diagnosis

When referred to this Section, perform the Electronic Engine Control (EEC-IV) Quick Test

The following codes may appear during the EEC-IV Quick Test. Service these codes first and repeat the EEC-IV Quick Test before continuing with the transmission diagnosis.

#### EEC-IV Quick Test Service Codes

- 26: TOT Out of Self-Test Range: The Transmission Oil Temperature (TOT) sensor registers a temperature not in the allowable range of testing. The test should be repeated with the transmission warmed to the correct testing temperature. (Refer to Engine/Emissions Diagnosis Shop Manual Volume H for correct temperature.)
- 47: 4x4 Switch Closed: Transmission transfer case is activated into four-wheel drive. Release four-wheel drive and repeat test.
- 65: Overdrive Cancel Switch Not Changing State: Operation of the Overdrive Cancel Switch was not recorded during the Engine On Quick Test. Service this switch as outlined in the Pin Point Tests in Engine/Emissions Diagnosis Manual Volume H.

- 67: MLPS Out of Range/AC On: If AC clutch is on during test, this code will appear. Shut off AC or defrost and repeat test. If the AC unit was off during the test, go to the code in the following Section.

If any of the following service codes appear during the EEC-IV Quick Test perform the Drive Cycle Test for continuous codes as outlined:

#### Transmission Quick Test Service Codes

- 49: 1-2 Shift Error: Engine speed drop during the 1 to 2 shift does not fall within tolerance limits.
- 56: -40 degree F indicated TOT, Sensor Circuit Open: Voltage drop across the TOT sensor exceeds the scale set for the temperature of -40 degrees F.
- 59: 2-3 Shift Error: Engine speed drop during the 2 to 3 shift does not fall within tolerance limits.
- 62: Converter Clutch Failure: The EEC-IV module picks up excessive amount of converter slip while converter is scheduled to be locked up.
- 66: 315 degrees F indicated TOT, Sensor Circuit Grounded: Voltage drop across the TOT sensor does not reach the scale set for the temperature of 315 degrees F.



- 67: MLPS Out of Range/AC On: Indicated voltage drop across the MLPS (Manual Lever Position Sensor) exceeds the limits established for each position. AC or Defrost on: Fault results from the AC clutch being on during Quick Test.
- 69: 3-4 Shift Error: Engine speed drop during the 3 to 4 shift does not fall within tolerance limit.
- 91: Shift Solenoid 1 Circuit Failure: Solenoid 1 circuit fails to provide voltage drop across solenoid. Circuit open or shorted, or EEC Driver failure.
- 92: Shift Solenoid 2 Circuit Failure: Solenoid 2 circuit fails to provide voltage drop across solenoid. Circuit open or shorted, or EEC Driver failure.
- 93: CCS Solenoid Circuit Failure: Solenoid 4 (Coast Clutch Solenoid) fails to provide voltage drop across solenoid. Circuit open or shorted, or EEC Driver failure.
- 94: CCC Solenoid Circuit Failure: Solenoid 3 (Converter Clutch Control Solenoid) fails to provide voltage drop across solenoid. Circuit open or shorted, or EEC Driver failure.
- 98: Failure Mode and Effects Management Failure/Failed EPC Output Driver: During the Quick Test, the voltage through the EPC (Electronic Pressure Control) solenoid is checked and compared to a voltage through the solenoid after a time delay. An error will be noted if the change tolerance is exceeded.
- 99: EPC Solenoid Circuit Failure/Short: Voltage measured across the Electronic Pressure Control Solenoid is less than a calculated minimum voltage.

## Drive Cycle Test

After performing the EEC-IV Quick Test, the following drive cycle test for checking E4OD continuous codes should be performed.

**NOTE:** Faults have to appear four times consecutively for continuous codes 49, 59 and 69 to be set, and five times consecutively for continuous code 62.

1. Record and zero EEC-IV Quick Test codes.
2. Verify that the transmission fluid level is correct.
3. Warm engine to operating temperature.
4. With transmission in  $\odot$  range, press the Overdrive Cancel Switch (LED light should illuminate) and moderately accelerate from stop to 64 Km/h (40 mph). This will allow the transmission to shift into third gear. Hold speed and throttle opening steady for a minimum of 15 seconds (30 seconds above 4000 feet altitude).

5. Press Overdrive Cancel Switch (LED light should turn off) and accelerate from 65 Km/h (40 mph) to 80 Km/h (50 mph). This will allow the transmission to shift into fourth gear. Hold speed and throttle position steady for a minimum of 15 seconds.
6. With transmission in fourth and maintaining steady speed and throttle opening, lightly apply and release brake (to operate stop lamps). Then hold speed and throttle steady for an additional 15 seconds minimum.
7. Brake to a stop and remain stopped for a minimum of 20 seconds with the transmission in  $\odot$  range.
8. Repeat Steps 4 through 6 at least five times.
9. Perform EEC-IV Quick-Test and record continuous codes.

If the codes appear, refer to the Pinpoint Test charted below for the appropriate service code.

**NOTE:** If any other service codes appear, service those codes first as they could affect the electrical operation of the transmission.

**NOTE:** After the servicing of any error codes resulting from the Quick Test, the Quick Test should be repeated.

## Electrical Diagnosis Chart Index

Error Codes	Pinpoint Test
49	AA
56	BB
59	AA
62	CC
66	BB
67	EE
69	AA
91	GG
92	GG
93	GG
94	GG
98	HH
99	HH





## Technical Service Information

### SERVICE CODES: 49, 59 AND 69 — PINPOINT TESTS AA

SERVICE CODES: 43, 53 AND 55



PINPOINT TESTS AA

TEST STEPS		RESULTS	ACTION TO TAKE						
AA1	CHECK HARNESS CONNECTIONS								
<ul style="list-style-type: none"><li>• Check that the vehicle harness connector is fully engaged on the transmission bulkhead connector.</li><li>• Check that the vehicle harness connector terminals are fully engaged in the connector.</li></ul>		<div>▶</div> <div>▶</div>	<div>GO to AA2.</div> <div>SERVICE or REPLACE as required. REPEAT QUICK TEST</div>						
AA2	CHECK RESISTANCE OF SOLENOID								
<p><b>NOTE: Refer to the E4OD Transmission Wiring Harness Terminal Locations and Color Codes preceding these Pinpoint Tests.</b></p> <ul style="list-style-type: none"><li>• Install service jumper harness to the transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Connect ohmmeter negative lead to the black wire on the service harness and the positive lead to the white wire on the service harness. This is to test solenoid 1.</li><li>• Record the resistance.</li><li>• Resistance should be between 20-30 ohms.</li><li>• Connect ohmmeter negative lead to the black wire on the service harness and the positive lead to the red wire on the service harness. This is to test solenoid 2.</li><li>• Record the resistance.</li><li>• Resistance should be between 20-30 ohms.</li></ul>		<div>20-30 ohms▶</div> <div>High resistance▶</div>	<div>GO to AA3.</div> <div>REPLACE solenoid body and REPEAT QUICK TEST</div>						
AA3	CHECK SOLENOID FOR SHORT TO GROUND								
<ul style="list-style-type: none"><li>• Install service jumper harness to transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Check for continuity between an engine ground and appropriate wire with an ohmmeter or other low current tester (less than 200 milliamps).</li></ul> <table><tr><th>Solenoid</th><th>Wire</th></tr><tr><td>1</td><td>White</td></tr><tr><td>2</td><td>Red</td></tr></table> <ul style="list-style-type: none"><li>• Connection should show no continuity (infinite resistance).</li></ul>		Solenoid	Wire	1	White	2	Red	<div>Continuity▶</div> <div>No continuity▶</div>	<div>REPLACE Solenoid Body. REPEAT QUICK TEST.</div> <div>GO to AA4.</div>
Solenoid	Wire								
1	White								
2	Red								

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.


## SERVICE CODES: 49, 59 AND 69 — PINPOINT TESTS AA (Continued)

TEST STEPS		RESULTS	ACTION TO TAKE
AA4	CHECK SOLENOID REGULATOR VALVE		
<ul style="list-style-type: none"><li>● Tear down to solenoid regulator valve.</li><li>● Inspect solenoid regulator valve for damage or contamination.</li><li>● Check for stuck or missing spring.</li></ul>		 ▶	CLEAR errors and REPEAT QUICK TEST
		 ▶	Service as required.

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.

### E4OD Test Harness T89T-70100-A





## Technical Service Information

### SERVICE CODES: 56 AND 66 — PINPOINT TESTS BB

TEST STEPS		RESULTS	ACTION TO TAKE																							
BB1	CHECK HARNESS CONNECTIONS	<div><div>OK</div><div><div>OK</div></div></div>	<div>GO to <b>BB2</b>.</div> <div>SERVICE or REPLACE as required. REPEAT QUICK TEST</div>																							
<div><div>• Check that the vehicle harness connector is fully engaged on the transmission bulkhead connector.</div><div>• Check that the vehicle harness connector terminals are fully engaged in the connector.</div></div>																										
BB2	CHECK TOT SENSOR RESISTANCE	<div>Resistance in range</div> <div>Resistance greater than 100K</div> <div>Resistance out of range</div>	<div>GO to <b>BB3</b>.</div> <div>REPLACE solenoid body and REPEAT QUICK TEST</div> <div>PERFORM SECOND TEST listed in this step. REPEAT QUICK TEST</div>																							
<div><div>NOTE: Refer to the E4OD Transmission Wiring Harness Terminal locations and Color Codes preceding these Pinpoint Tests.</div><div><div>• Install service jumper harness to the transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</div><div>• Carefully touch the transmission oil pan on the driver's side, away from the exhaust system, to approximate the temperature. After running the Quick Test, the transmission oil pan should be warm to the touch. (As a guide, warm to the touch is about 41-70 degrees C [105-158 degrees F]).</div><div>• Connect ohmmeter negative lead and the positive lead to the yellow wires on the service harness.</div><div>• Record the resistance.</div><div>• Resistance should be approximately in the following ranges.</div></div><table><tr><th colspan="3">TRANSMISSION FLUID TEMPERATURE</th></tr><tr><th>Degrees C</th><th>(Degrees F)</th><th>Resistance (Ohms)</th></tr><tr><td>0- 20</td><td>( 32- 58)</td><td>37K- 100K</td></tr><tr><td>21- 40</td><td>( 59-104)</td><td>16K- 37K</td></tr><tr><td>41- 70</td><td>(105-158)</td><td>5K- 16K</td></tr><tr><td>71- 90</td><td>(159-194)</td><td>2.7K- 5K</td></tr><tr><td>91-110</td><td>(195-230)</td><td>1.5K- 2.7K</td></tr><tr><td>111-130</td><td>(231-266)</td><td>0.8K- 1.5K</td></tr></table><div><div>• If the resistance was not the appropriate temperature range but was between 0.8K and 100K ohms, perform the following test. If the transmission is cold, run the transmission to heat it up. If the transmission is warm, allow the transmission to cool. Check TOT sensor resistance again. Compare the resistance with the initial resistance. Resistance should decrease if transmission was heated and should increase if transmission was allowed to cool. If the correct change in resistance occurs, REPEAT QUICK TEST.</div></div></div>		TRANSMISSION FLUID TEMPERATURE			Degrees C	(Degrees F)	Resistance (Ohms)	0- 20	( 32- 58)	37K- 100K	21- 40	( 59-104)	16K- 37K	41- 70	(105-158)	5K- 16K	71- 90	(159-194)	2.7K- 5K	91-110	(195-230)	1.5K- 2.7K	111-130	(231-266)	0.8K- 1.5K	
TRANSMISSION FLUID TEMPERATURE																										
Degrees C	(Degrees F)	Resistance (Ohms)																								
0- 20	( 32- 58)	37K- 100K																								
21- 40	( 59-104)	16K- 37K																								
41- 70	(105-158)	5K- 16K																								
71- 90	(159-194)	2.7K- 5K																								
91-110	(195-230)	1.5K- 2.7K																								
111-130	(231-266)	0.8K- 1.5K																								

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.



## Technical Service Information

### SERVICE CODES: 56 AND 66 — PINPOINT TESTS BB — Continued

TEST STEPS		RESULTS	ACTION TO TAKE
<b>BB3</b>	CHECK TOT SENSOR FOR SHORT TO GROUND		
<ul style="list-style-type: none"><li>• Install service jumper harness to transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Check for continuity between engine ground and one yellow wire with an ohmmeter or other low current tester (less than 200 milliamps).</li><li>• Repeat the continuity check with the other yellow wire.</li><li>• Connection should show no continuity (infinite resistance).</li></ul>		Continuity	REPLACE solenoid body and REPEAT QUICK TEST. REPEAT QUICK TEST
		No continuity	If code was a continuous code, inspect transmission fluid to determine if fluid is burnt. If burnt, teardown transmission and inspect for damage. SERVICE as required and REPEAT QUICK TEST

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.



## Technical Service Information

### SERVICE CODE: 62 — PINPOINT TEST CC

TEST STEPS		RESULTS	ACTION TO TAKE
CC1	CHECK HARNESS CONNECTIONS		
	<ul style="list-style-type: none"><li>• Check that the vehicle harness connector is fully engaged on the transmission bulkhead connector.</li><li>• Check that the vehicle harness connector terminals are fully engaged in the connector.</li></ul>	<div>OK ►</div> <div>OK/NO ►</div>	<div>GO to CC2.</div> <div>SERVICE or REPLACE as required. REPEAT QUICK TEST</div>
CC2	CHECK RESISTANCE OF SOLENOID		
	<p><b>NOTE: Refer to the E4OD Transmission Wiring Harness Terminal locations and Color Codes preceding these Pinpoint Tests.</b></p> <ul style="list-style-type: none"><li>• Install service jumper harness to the transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Connect ohmmeter negative lead to the black wire on the service harness and the positive lead to the green wire on the service harness. This is to test converter clutch solenoid.</li><li>• Record the resistance.</li><li>• Resistance should be between 20-30 ohms.</li></ul>	<div>20-30 ohms ►</div> <div>High resistance ►</div>	<div>GO to CC3.</div> <div>REPLACE solenoid body and REPEAT QUICK TEST</div>
CC3	CHECK SOLENOID FOR SHORT TO GROUND		
	<ul style="list-style-type: none"><li>• Install service jumper harness to transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Check for continuity between engine ground and green wire with an ohmmeter or other low current tester (less than 200 millilamps).</li></ul>	<div>No continuity ►</div> <div>Continuity ►</div>	<div>GO to CC4.</div> <div>Replace Solenoid Body and REPEAT QUICK TEST</div>
CC4	CHECK CONVERTER CLUTCH REGULATOR VALVE AND CONVERTER CLUTCH CONTROL VALVE		
	<ul style="list-style-type: none"><li>• Tear down to converter clutch regulator valve and converter clutch control valve.</li><li>• Inspect valves for damage or contamination.</li><li>• Check for struck or missing spring.</li></ul>	<div>OK ►</div> <div>OK/NO ►</div>	<div>CLEAR errors and REPEAT continuous drive tests. If errors persist, refer to Mechanical Diagnosis in this section.</div> <div>SERVICE as required.</div>

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.


**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.





## Technical Service Information

### SERVICE CODE: 67 — PINPOINT TEST EE

TEST STEPS		RESULTS	ACTION TO TAKE
EE1	ADJUST MANUAL LEVER POSITION SENSOR		
<ul style="list-style-type: none"><li>• Apply the parking brake.</li><li>• Place transmission in Neutral position.</li><li>• Verify that Manual Lever Position Sensor Tool T89T-20010-J fits in appropriate slots.</li></ul>		<p>OK →</p> <p>✗ →</p>	<p>GO to EE2.</p> <p>ADJUST sensor according to adjustment procedures in this manual and REPEAT QUICK TEST</p>
EE2	CHECK OPERATION OF MANUAL LEVER POSITION SENSOR		
<ul style="list-style-type: none"><li>• Insert Manual Lever Position Sensor test harness into the Manual Lever Position Sensor connector.</li><li>• Plug test box into power supply</li><li>• With transmission in Park, press the buttons on the box. The GOOD light should light only when the P button is pushed. Repeat the test for R, N, , 2 and 1.</li></ul>		<p>OK →</p> <p>✗ →</p>	<p>REPEAT QUICK TEST</p> <p>REPLACE Manual Lever Position Sensor and REPEAT QUICK TEST</p>

### HOW TO CLEAR THE CONTINUOUS MEMORY CODES

**NOTE:** Do not disconnect battery to clear Continuous Memory Codes. This will erase the Keep Alive Memory (KAM) information which may cause a driveability concern.

1. Run the Key On Engine Off Self-Test according to Quick Test Step 3.0A.
2. When the Service Codes begin to be displayed, deactivate Self-Test:
  - STAR Tester: Unlatching the center button (up position).
  - Analog VOM: Remove the jumper wire from between Self-Test Input (STI) connector and the Signal Return Pin of the Self-Test connector.
  - "Check Engine" Light (MIL): Remove the jumper wire from between Self-Test Input (STI) connector and the SIGNAL RETURN pin of the Self-Test connector.
  - Message Center (Continental Only): Remove the jumper wire from between Self-Test input (STI) connector and the SIGNAL RETURN pin of the Self-Test connector.
3. The Continuous Memory codes will be erased from the processor's memory.



## Technical Service Information

### SERVICE CODES: 91, 92, 93 AND 94 — PINPOINT TEST GG

TEST STEPS		RESULTS	ACTION TO TAKE										
GG1	CHECK HARNESS CONNECTIONS												
<ul style="list-style-type: none"><li>• Check that the vehicle harness connector is fully engaged on the transmission bulkhead connector.</li><li>• Check that the vehicle harness connector terminals are fully engaged in the connector.</li></ul>		<div>OK</div> <div><del>OK</del></div>	<div>GO to GG2.</div> <div>SERVICE or REPLACE as required. REPEAT QUICK TEST</div>										
GG2	CHECK RESISTANCE OF SOLENOID												
<p><b>NOTE: Refer to the E4OD Transmission Wiring Harness Terminal locations and Color Codes preceding these Pinpoint Tests</b></p> <ul style="list-style-type: none"><li>• Install service jumper harness to the transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Connect ohmmeter negative lead to the black wire on the service harness and the positive lead to the appropriate wire on the service harness.</li></ul> <table><tr><th>Error Code</th><th>Wire</th></tr><tr><td>91</td><td>White</td></tr><tr><td>92</td><td>Red</td></tr><tr><td>93</td><td>Green</td></tr><tr><td>94</td><td>Blue</td></tr></table> <ul style="list-style-type: none"><li>• Record the resistance.</li><li>• Resistance should be between 20-30 ohms.</li></ul>		Error Code	Wire	91	White	92	Red	93	Green	94	Blue	<div>20-30 ohms</div> <div>High resistance</div>	<div>GO to GG3.</div> <div>REPLACE solenoid body and REPEAT QUICK TEST</div>
Error Code	Wire												
91	White												
92	Red												
93	Green												
94	Blue												
GG3	CHECK SOLENOID FOR SHORT TO GROUND												
<ul style="list-style-type: none"><li>• Install service jumper harness to transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Check for continuity between engine ground and appropriate wire with an ohmmeter or other low current tester (less than 200 milliamps).</li></ul> <table><tr><th>Error Code</th><th>Wire</th></tr><tr><td>91</td><td>White</td></tr><tr><td>92</td><td>Red</td></tr><tr><td>93</td><td>Green</td></tr><tr><td>94</td><td>Blue</td></tr></table> <ul style="list-style-type: none"><li>• Connection should show no continuity (infinite resistance).</li></ul>		Error Code	Wire	91	White	92	Red	93	Green	94	Blue	<div>Continuity</div> <div>No continuity</div>	<div>REPLACE solenoid body and REPEAT QUICK TEST</div> <div>REPEAT QUICK TEST</div>
Error Code	Wire												
91	White												
92	Red												
93	Green												
94	Blue												

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.



## Technical Service Information

### SERVICE CODES: 98 AND 99 — PINPOINT TEST HH

TEST STEPS		RESULTS	ACTION TO TAKE
HH1	CHECK HARNESS CONNECTIONS		
<ul style="list-style-type: none"><li>• Check that the vehicle harness connector is fully engaged on the transmission bulkhead connector.</li><li>• Check that the vehicle harness connector terminals are fully engaged in the connector.</li></ul>		<div>OK</div> <div>OK</div>	<div>GO to HH2.</div> <div>SERVICE or REPLACE as required. REPEAT QUICK TEST</div>
HH2	CHECK RESISTANCE OF SOLENOID		
<p><b>NOTE: Refer to the E4OD Transmission Wiring Harness Terminal locations and Color Codes preceding these Pinpoint Tests.</b></p> <ul style="list-style-type: none"><li>• Install service jumper harness to the transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Connect ohmmeter negative lead and positive lead to the orange wires on the service harness.</li><li>• Record the resistance.</li><li>• Resistance should be between 4.0-6.5 ohms.</li></ul>		<div>4.0-6.5 ohms</div> <div>High resistance</div>	<div>GO to HH3.</div> <div>REPLACE solenoid body and REPEAT QUICK TEST</div>
HH3	CHECK SOLENOID FOR SHORT TO GROUND		
<ul style="list-style-type: none"><li>• Install service jumper harness to transmission bulkhead connector. (Do not pry vehicle harness connector off with a screwdriver.)*</li><li>• Check for continuity between engine ground and one of the orange wires with an ohmmeter or other low current tester (less than 200 milliamps).</li><li>• Repeat the continuity check with the other orange wire.</li><li>• Connection should show no continuity (infinite resistance).</li></ul>		<div>Continuity</div> <div>No continuity</div>	<div>REPLACE solenoid body and REPEAT QUICK TEST</div> <div>REPEAT QUICK TEST</div> <div>Problem should not reoccur if the solenoid body passed previous tests.</div>

\*Remove solenoid body connector by pushing on the center tab and pulling on the wiring harness.

**CAUTION:** Do not attempt to pry tab with a screwdriver. Remove heat shield from transmission before removing connector.




## Teardown


Refer to the transmission disassembled view at the beginning of this Section.

### Disassembly

Remove input shaft from transmission.




Rotate transmission so that pan is facing up. Remove 20 pan attaching bolts (10mm socket). Remove the pan and gasket, discard gasket.




Remove filter and seal assembly by carefully pulling and rotating filter as necessary. If seal remains in bore, carefully remove using O-Ring Tool T71P-19703-C or equivalent.

NOTE: Discard filter and seal.




Mount transmission on Twin Post Engine Stand Rotunda 014-00106 or equivalent.


NOTE: Thoroughly clean the solenoid body connector area to avoid contamination.



Remove accumulator body, 11 bolts (8mm socket) and two nuts (10mm socket).




Remove nine solenoid body bolts (30A Torx® bit) and one nut (10mm socket).




Remove main control body 14 bolts (8mm socket) two nuts (10mm socket).

NOTE: Do not remove the two bolts as shown.

DO NOT REMOVE  
THESE TWO BOLTS




Push up on solenoid body connector while removing solenoid body.






## Technical Service Information

Remove solenoid screen, by turning counterclockwise and pull out.




Remove separator plate, two gaskets, EPC ball and blowoff spring, discard gasket.




Remove three reinforcing plate bolts (8mm socket), remove plate.

NOTE: EPC ball is spring loaded under separator plate.



Remove one steel and ten rubber check balls from transmission, using a small screwdriver.

**CAUTION: Do not mar rubber check balls.**





CHECKBALL  
LEGEND

- △ - STEEL (1)
- - RUBBER (10)




Remove servo snap ring and retaining plate, piston and rod assembly and servo spring.

NOTE: Apply slight downward pressure to plate while removing snap ring.




Remove three feed bolts (13mm socket). Discard feed bolts.







Rotate transmission so that bell housing is facing up. Remove nine pump bolts, (10mm socket). Discard pump bolt washers.




Remove pump gasket and No. 7D014 thrust washer. Discard gasket.



Use two threaded holes in pump and install Pump Puller Adapter T89T-70010-A or equivalent. Install Slide Hammer T59L-100-B or equivalent into adapter and remove pump.




Lift out the coast clutch assembly.




Remove needle bearing assembly 7E486 between front pump and sun gear.

NEEDLE BEARING  
THRUST WASHER  
7E486




Remove overdrive pressure plate and clutch pack and tag for re-assembly.




OVERDRIVE  
PRESSURE PLATE  
AND CLUTCH PACK

Remove large snap ring using large screwdriver.




SNAP  
RING

22. Remove overdrive ring gear and center shaft assembly and needle bearing assembly 7G178.



OVERDRIVE RING  
GEAR AND  
CENTER SHAFT  
ASSEMBLY




NEEDLE BEARING  
ASSEMBLY-7G178


OVERDRIVE RING  
GEAR AND  
CENTER SHAFT ASSEMBLY

VIEW A

Install Clutch Spring Compressor T89T-70010-F or equivalent into the case. Tighten center bolt to 7 N·m (65 in-lbs).



Remove intermediate/overdrive cylinder assembly.




CLUTCH SPRING  
FIXTURE  
T89T-70010-C


CLUTCH SPRING  
COMPRESSOR BAR  
T88C-77000-AH-2

CLUTCH SPRING  
COMPRESSOR PLATE  
T89T-70010-F

TOOL ASSEMBLY  
VIEW A




Remove intermediate return spring.




Remove large snap ring with large screwdriver. Loosen spring compressor center bolt and remove compressor tool.

CLUTCH SPRING  
COMPRESSOR  
BAR  
T88C-77000-AH-2


SNAP  
RING




Remove center support.




Remove intermediate pressure plate and clutch plates. Tag clutch plates for re-assembly.



Remove thrust washer No. 7L326.




Remove intermediate band.




Remove direct clutch forward clutch and shell using Clutch Remover/Installer T89T-70010-E or equivalent.

NOTE: Hooks on crossbar must be rotated into notches on input shell. Refer to illustration.


INTERMEDIATE  
BAND




Remove reverse planet carrier and two thrust washers No. 7D423.




Using large screwdriver, remove reverse snap ring.




Using Snap Ring Pliers, remove the output shaft snap ring. Discard snap ring.




Remove ring gear and hub assembly, and needle bearing assembly No. 7E413.




Using a large screwdriver remove reverse clutch snap ring.



Remove reverse hub and one-way clutch assembly.




Remove reverse pressure plate and clutch pack. Tag for re-assembly.






Rotate transmission so that pan surface is facing up.


Remove nine extension housing bolts (13mm socket). Remove wiring bracket, extension housing and gasket, (discard gasket).




Remove reverse clutch, return spring and inner race.




Remove output shaft, park gear and thrust washer No. 7B368.



**CAUTION:** Install reverse clutch pressure plate and snap ring, to hold reverse clutch piston during removal.




Remove five bolts (11mm socket) from the low/reverse one-way clutch inner race.








Using side cutters or Locknut Pin Remover T78P-3504-N or equivalent remove manual lever roll-pin from the case.




Remove inner detent lever nut (21mm box wrench), while holding lever with crescent wrench.




Remove inner detent lever and parking pawl actuating rod assembly from manual lever.



Blow air into reverse clutch feed port using compressed air. This will blow out the reverse clutch piston against the pressure plate.




Remove two bolts (13 mm socket) from parking rod guide plate.




Remove snap ring, reverse clutch pressure plate and piston from case.

Rotate transmission so that pan surface is facing down.


Remove park pawl return spring, pin and parking pawl from case.




Remove the Torx® head bolt (40A bit) and parking pawl abutment.




Remove two bolts (8mm socket) and manual lever position sensor.




Remove manual lever seal using Seal Remover T74P-77248-A and Slide Hammer T50T-100-A or equivalents.



Remove manual lever.




If required, remove stub tube, using channel lock pliers.




## Assembly

### Assembly

Mount transmission in Twin Post Engine Stand Rotunda 014-00106 or equivalent.



### Rear View




Rotate transmission so that bell housing is facing up.


Install inner and outer seals on the reverse clutch piston.

Install reverse clutch piston using Clutch Spring Compressor T65L-77515-A or equivalent. Remove tool after installing piston.

### Front View




Install reverse piston return spring assembly and one-way clutch inner race.



Attach to case with five bolts (11mm socket) and tighten to 25-33 N·m (18-25 ft-lb).


FIVE LOW/REVERSE  
ONE-WAY CLUTCH  
INNER RACE BOLTS



Rotate transmission to horizontal position.

Grease steel side of the thrust washer No. 7B368 and place on rear of case so that bronze side is facing outward.

THRUST WASHER  
7B368




Install a six internal spline plate reverse clutch pack starting with an external spline plate. Alternate external spline plates with internal spline plates. Install snap ring.

NOTE: No stack-up clearance measurement required.


REVERSE PRESSURE  
PLATE AND  
CLUTCH PACK

SNAP  
RING




Install snap ring onto output shaft. Slide park gear onto shaft with thrust surface opposite snap ring. Install output shaft.

**WARNING: DO NOT OVEREXTEND SNAP RING WHEN INSTALLING. ENSURE SNAP RING IS SECURELY SEATED IN GROOVE.**



Install reverse hub and low/reverse one way clutch.


REVERSE HUB AND  
LOW/REVERSE  
ONE WAY CLUTCH  
ASSEMBLY



Install new snap ring onto output shaft.


**WARNING: DO NOT OVEREXTEND SNAP RING WHEN INSTALLING. ENSURE SNAP RING IS SECURELY SEATED IN GROOVE.**

SNAP  
RING



Install output shaft hub and reverse ring gear, placing needle needle bearing assembly No. 7E413 on rear surface of hub. Hold bearing in place with grease.

NEEDLE BEARING  
ASSEMBLY  
7E413




RING AND HUB  
ASSEMBLY

Install reverse plate carrier assembly into hub with thrust washer No. 7D423.

REVERSE  
PLANET  
CARRIER


THRUST  
WASHER  
7D423

THRUST  
WASHER  
7D423






Install snap ring.



Install intermediate band so that one ear is resting on the reaction pin.




Rotate transmission so that bell housing is facing up.

Attach Clutch Remover/Installer T89T-70010-E or equivalent, onto input shell and lower entire assembly (Intermediate Brake Drum Assembly, Forward Clutch Assembly and Input Shell Assembly) into case.


NOTE: It may be necessary to rotate output shaft to seat reverse sun gear.

Remove service tool.




Install servo snap ring, retaining plate, piston and rod assembly and servo spring.


NOTE: Apply slight downward pressure to plate while removing snap ring.







Install intermediate pressure plate. Install clutch pack starting with internal spline plate. Install apply plate.




Determine end play with following procedure:

The transmission rear end play check determines:

The amount of space existing between the thrust washer surfaces of the center support and the intermediate brake drum. (2.06-.81mm) (.081-.032 inch)


Install center support, align with holes in feed port. Install the two feed bolts. Do not tighten at this time.



Install intermediate/overdrive cylinder assembly into case.

NOTE: Align cylinder assembly locator tab with center support and feel hole with hole in case. Install one feed bolt but do not tighten it.


CAUTION: Do not cock cylinder when installing.




Install intermediate clutch return spring with dished surface inward.

NOTE: Locate one spring leg pointing to the top of the transmission as illustrated.



NOTE: Intermediate clutch return spring locator legs must be properly located inside of center support circular cast rib.




Install trial selective snap ring over intermediate clutch cylinder assembly so that ring opening is at bottom of case for proper oil drainback. Place Clutch Spring Compressor Plate T89T-70010-F and Intermediate Clutch Spring Fixture T89T-70010-C or equivalents onto intermediate clutch cylinder assembly.



Tighten center bolt to 7 N·m (65 in-lb). Seat selective snap ring into case ring groove.



Attach Dial Indicator with Magnetic Base D78P-4201-B or equivalent to bar. Place stylus onto Compressor Plate T89T-70010-F or equivalent and zero dial.



Release torque on center bolt and note reading on indicator. If reading is not within specifications, repeat procedure using the correct selective snap ring.

## Specifications:

1.37 - 0.67mm (0.054 - 0.026 inch)

## Selective Snap Rings:


1.55 - 1.45mm (0.061 - 0.057 inch)

2.05 - 1.95mm (0.080 - 0.076 inch)


2.60 - 2.50mm (0.100 - 0.098 inch)

32. Remove Clutch Spring Tool Assembly. Tighten three feed bolts (13mm socket) into intermediate/overdrive cylinder assembly and center support.


**CAUTION:** Tighten the front feed bolt to 9-13 N·m (6-10 ft-lbs). Tighten both rear feed bolts to 11-16 N·m (8-12 ft-lbs).




Using grease, place needle bearing assembly No. 7G178 on rear face of center shaft. Install center shaft, overdrive ring gear, overdrive planetary gearset and coast clutch cylinder as an assembly.



Install overdrive clutch pack starting with steel plate. Install pressure plate with dot facing outward and toward the top of the transmission. Install trial selective snap ring with opening at bottom of case.



Install pump gasket into case.



Check stack-up clearance using a feeler gauge. If not within specification, install correct selective snap ring and recheck.

## Specification:

1.20 - 0.55mm (0.047 - 0.022 inch)

## Selective Snap Rings


1.55 - 1.45mm (0.061 - 0.057 inch)

2.05 - 1.95mm (0.80 - 0.076 inch)

2.60 - 2.50mm (0.10 - 0.098 inch)


3.10 - 3.00mm (0.12 - 0.118 inch)

3.60 - 3.50mm (0.14 - 0.137 inch)




Screw Pump Puller Adaptors T89T-70010-A or equivalent into pump threaded holes. Screw on Impact Slide Hammers T59L-100-B or equivalent.


Install thrust washer No. 7D014 and needle bearing assembly 7E486 onto pump. Use grease to hold in place.



Install input shaft (long splined end first) and Alignment Pin T89T-70010-B or equivalent into the case as shown. Install the pump into the case. Orient the filter inlet tube bore towards the valve body mounting surfaces.




Install manual lever seal using Shift Lever Seal Replacer T74P-77498-A or equivalent.




Remove old rubber coated washers from the nine pump to case bolts. Install new pump bolt washers. Remove Aligning Pin T89T-70010-B. Install pump using nine bolts (10mm socket). Tighten to 24-31 N·m (18-23 ft-lb).

**NOTE:** Draw pump into case evenly to avoid seal damage.

**CAUTION:** Remove input shaft.



Install manual lever detent spring bolt (8mm socket). Tighten to 9-11 N·m (80-100 in-lb).









## Technical Service Information


Install manual lever, inner lever, park actuating rod assembly and nut (21mm box wrench).



Install manual lever roll so that pin is just below case surface.




Tighten manual lever nut (13/16 crows foot) to 41-54 N·m (30-40 ft-lbs).




Install parking pawl, pin and parking pawl return spring on rear face.


NOTE: Parking pawl return spring end rests on inside surface of case.



Install parking pawl abutment with Torx® head bolt (40A bit) and tighten to 22-27 N·m (16-20 ft. lbs.).




Install manual lever position sensor with two bolts (8mm socket) and washers. Do not tighten bolts at this time. Align manual lever position sensor for neutral gear position using Gear Position Sensor Adjuster T89T-70010-J or equivalent.




Attach parking rod guide plate with two bolts (13mm socket) and washers. Tighten to 22-27 N·m (16-20 ft. lbs.).

NOTE: Ensure plate dimple is facing inward.




Tighten bolts (8mm socket) and washer to 6-8 N·m (55-75 in. lb.).







## LATE-1989 CASE CHECKBALL LOCATIONS REQUIRES FOURTEEN 5/16" RUBBER BALLS




## LATE-1989 CASE CHECKBALL LOCATIONS REQUIRES TEN 5/16" RUBBER BALLS, AND ONE 5/16" STEEL BALL, TOTAL 11




## 1990-1995 CASE CHECKBALL LOCATIONS REQUIRES NINE 5/16" RUBBER BALLS




## 1996-1998 CASE CHECKBALL LOCATIONS REQUIRES EIGHT 5/16" RUBBER BALLS



## 1989-1995 VALVE BODY CHECKBALL LOCATIONS TWO 5/16" RUBBER BALLS - ALL MODELS



## 1996-1998 VALVE BODY CHECKBALL LOCATIONS REQUIRES THREE 1/4" RUBBER BALLS, AND TWO 5/16" RUBBER BALLS




### SPECIAL NOTE:


Some 1995 models were built with 1996 production valve body, spacer plate, and valve body gaskets. Be very careful to identify the parts on any 1995 model properly.

Copyright © 2003 ATSG

Install case-to-separator plate gasket.




Attach reinforcing plate with three bolts (8mm socket) with stamped "up" facing up. Tighten to 9-11 N·m (80-100 in-lb).




NOTE: Check placement of EPC blow-off ball.


Install separator plate.




57. Install new separator-to-control gasket.




Install solenoid screen into separator plate.  
Turn and lock solenoid screen.



Lower main control body over studs. Align  
manual valve with manual lever.




Install accumulator body over studs and attach  
with two nuts (10mm socket) and 11 bolts (8mm  
socket). Tighten to 9-11 N·m (80-100 in-lb).




TIGHTEN BOLTS AND  
NUTS TO  
9-11 N·m  
(80-100 IN-LB)

ACCUMULATOR  
BODY




Attach valve body with two nuts (10mm socket)  
and 14 bolts (8mm socket). Tighten to 9-11  
N·m (80-100 in-lb).






Install solenoid body over stud and attach with nine Torx® bolts (30A bit) and one nut (10mm socket). Tighten to 9-11 N·m (80-100 in-lb).

NOTE: Prior to installing solenoid body assembly, coat the case connector bore with M1C172-A grease or equivalent.




TIGHTEN TORX® BOLTS  
AND NUT TO  
9-11 N·m  
(80-100 IN-LB)

SOLENOID  
BODY




Place pan magnet on dimple in bottom of pan. Install new pan gasket. Use grease to hold in place.




TIGHTEN BOLTS  
TO 14-16 N·m  
(10-12 FT-LB)

Install a new filter and seal assembly by lubricating the seal with transmission fluid and pressing the filter into place. Do not reuse old filter or seal.




FILTER  
AND SEAL  
ASSEMBLY



Reinstall input shaft, long splined end first.

## Main Control Valve Body and Valve Body

### Valve Body





## Technical Service Information

### Legend—Main Control Valve Body and Valve Body


Description	Part Number	Description	Part Number
1. Main Control Body	7A092	36. 1-2 Manual Transition Valve	7G414
2. Manual Valve	7340	37. Spring	7K721
3. Retainer	97411-S	38. Retainer	7F194
4. Low/Reverse Modulator Valve	7E238	39. Accumulator Body	7G393
5. Spring	7E338	40. Overdrive Clutch Accumulator Regulator Valve	7G321
6. Retainer	7F194	41. Spring	7G310
7. 3-4 Shift Valve	7F259	42. Retainer	7G409
8. Spring	7K721	43. Overdrive Clutch Accumulator Plunger	7G322
9. Plug	7F187	44. Outer Spring	7G394
10. Clip	7E335	45. Inner Spring	7G395
11. 2-3 Shift Valve	7D053	46. Plug	7F187
12. Spring	7A320	47. Clip	7E335
13. Retainer	7F194	48. Direct Clutch Accumulator Regulator Valve	7G321
14. D2 Shift Valve	7D368	49. Spring	7G310
15. Spring	7A288	50. Retainer	7G409
16. 1-2 Shift Valve	7A334	51. Direct Clutch Accumulator Plunger	7G322
17. Plug	7F187	52. Outer Spring	7G394
18. Clip	7E335	53. Inner Spring	7G395
19. 4-3-2 Manual Timing Valve	7G398	54. Plug	7F187
20. Spring	7G410	55. Clip	7E335
21. Retainer	7G396	56. Intermediate Clutch Accumulator Regulator Valve	7G321
22. 4-3-2 Manual Timing Plunger	7G399	57. Spring	7G310
23. Plug	7F187	58. Retainer	7G409
24. Clip	7E335	59. Intermediate Clutch Accumulator Plunger	7G322
25. Coast Clutch Shift Valve	7G416	60. Outer Spring	7G394
26. Spring	7K721	61. Inner Spring	7G395
27. Retainer	7F194	62. Plug	7F187
28. Solenoid Regulator Valve	7G392	63. Clip	7E335
29. Spring	7G411	64. Line Pressure Modulator Valve	7G408
30. Retainer	7F194	65. Outer Spring	7G314
31. Separator Plate	7A008	66. Spring and Retainer Assembly	7H149
32. Lower Control Body	7A101	67. Line Pressure Modulator Plunger Valve	7G415
33. Engagement Control Valve	7G317	68. Line Pressure Modulator Sleeve	7G407
34. Spring	7G312	69. Clip	7E335
35. Retainer	7F194	70. Check Ball	7E195





## Component Assembly

### Subassemblies Pump



AUTOMATIC TRANSMISSION SERVICE GROUP



## Technical Service Information

Description	Part Number	Description	Part Number
1. Pump Body	7A105	20. Plug	7F187
2. Control Body	7G406	21. Clip	7E335
3. Square Cut O.D. Pump Seal	7D441	22. Solid Cup Plug	N805212
4. Converter Hub Bushing	7B258	23. Solid Cup Plug	N805212
5. Seal	7A248	24. Solid Cup Plug	N805212
6. Bolt and Washer Assembly	N805260	25. Solid Cup Plug	N805212
7. Main Regulator Valve	7C338	26. Solid Cup Plug	N805212
8. Spring Retainer	7E337	27. Orificed Cup Plug (.077-.083 inch diameter orifice)	N805213
9. Outer Spring (Green)	7A270	28. Orificed Cup Plug (.049-.055 inch diameter orifice)	N805214
10. Inner Spring (Green)	7G498	29. Air Bleed Check Valve Assembly	7H000
11. Main Regulator Booster Valve	7D003	30. Inner Gerotor Gear	7C010
12. Main Regulator Booster Sleeve	7D002	31. Outer Gerotor Gear	7C011
13. Retainer	N660225	32. Orifice Cup Plug (.057-.062 inch diameter orifice)	N805802
14. Converter Regulator Valve	7G307	33. Valve Assembly	7A250
15. Spring (White)	7G316	34. Solid Cup Plug	N805175
16. Plug	7F187	35. Front Input Shaft Bushing	7B261
17. Clip	7G007	36. Rear Input Shaft Bushing	7D018
18. Converter Clutch Control Valve	7L318		
19. Spring (Yellow)	7L490		

### Pump Disassembly

Remove two Teflon® coast clutch seals from stator support. Remove converter clutch seal from front of stator support. Remove pump outer diameter square cut seal.

Obtain a banding tool prior to removing pump body bolts. This tool is needed to align the pump with the control body assembly during re-assembly.

Remove eleven bolts and separate pump control body from pump body.

For Steps 4 through 6 refer to pump control body assembly illustration.

Apply pressure to main regulator booster sleeve and remove internal snap ring. Remove main regulator valve train.


Remove converter regulator valve assembly by applying pressure to end plug and removing retainer clip with small screwdriver or tweezers.

Remove converter clutch shift valve assembly by applying pressure to end plug and removing retainer clip with small screwdriver or tweezers.

NOTE: DO NOT remove any of the cup plugs unless they are damaged or leaking.

NOTE: DO NOT remove stator support from control body as this may distort the surface of the control body.



Remove gerotor gearset from pump body.




Remove gasket material from control body surface. Clean all pump parts in solvent and dry with compressed air.

Inspect pump gears, faces, gear teeth, pump housing and mating surfaces for damage or scoring. Replace entire pump if any part is damaged or worn.



Inspect converter hub bushing. Replace if scored or excessively worn. Install as shown. Stake bushing at notches.



Inspect converter hub seal. If damaged, remove with Impact Slide Hammer Tool no. T59L-100-B and Seal Remover Tool no. 1175-AC. Install new seal with Seal Installer Tool no. T63L-77837-A.



Inspect stator input shaft bushings. If bushings are worn or scored, replace complete control body assembly.



Inspect all valve and plug bores for scoring, or damage. Check all passages for obstructions. Inspect mating surfaces for burrs and scoring. If necessary, use crocus cloth to polish components. Use caution to avoid rounding sharp edges of valves and plugs.


Inspect all springs for distortion. Check all valves and plugs that when dry they fall freely from their bores.

## Assembly

Install main regulator valve assembly as shown in control body assembly drawing. Apply pressure to main regulator booster sleeve and install internal snap ring. Ensure snap ring is properly seated.

Install converter shuttle valve assembly as shown in pump exploded view.


Lightly coat the gerotor gears and install in pump housing. The dot on the inner gerotor gear must face the control body assembly.





Inspect mating surfaces of pump body and control body to be sure they are clean and free of nicks and burrs. Lower the control body and stator assembly onto the pump body, aligning the 28mm round hole in the control body with the 28mm hole in the pump body.



Loosely install eleven M8x50 bolts into pump body. Install banding tool no D89L-77000- or equivalent with clamp by filter inlet. Align outer bolt holes and tighten banding tool. (This aligns input shaft bushings to the converter hub bushings.)

Tighten bolts to 24-31 N·m (18-23 ft. lbs.) and remove banding tool. Ensure the outer edges of the control body and the pump body are completely aligned.






Install pump outer diameter seal. Be sure groove is clean and free of burrs. Lubricate outer diameter seal with transmission fluid before installing pump into transmission case.




## Coast Clutch Cylinder Assembly




### Disassembly

Complete assembly shown.

COAST CLUTCH CYLINDER ASSEMBLY




Remove sun gear assembly from coast clutch cylinder.







Remove snap ring and discard.




Remove pressure and clutch plates from cylinder. Tag for re-assembly.



Using Clutch Spring Compressor T65L-77515-A or equivalent remove return spring retaining ring. Remove compressor tool.



Remove piston return spring.









## Technical Service Information


Remove piston apply plate.



Remove inner seal from cylinder.



Remove piston from cylinder.




### Assembly


NOTE: Soak all friction plates in clean transmission fluid ESP-M2C166-H or equivalent for 15 minutes.

Lightly lube all O-ring seals before installing using transmission fluid ESP-M2C66-H or equivalent.


Install inner seal so that lip is facing toward bottom (down) into cylinder.




Remove outer seal from piston.




Install outer seal so that lip is facing toward bottom (down) onto piston.




Install piston apply plate.



Install piston into cylinder.




Install piston return spring.





## Technical Service Information

Using Clutch Spring Compressor T65L-77515-A or equivalent, install snap ring.



Install selective snap ring and check stack-up using feeler gauge. If not within specification, install correct selective snap ring and recheck.

### Specification:


1.14 - 0.62mm (0.045 - 0.025 inch)

### Selective Snap Rings

1.45 - 1.35mm (0.057 - 0.053 inch)

1.85 - 1.75mm (0.072 - 0.068 inch)


2.25 - 2.15mm (0.088 - 0.084 inch)




Install clutch pack plates, alternately starting with steel plate.

NOTE: Soak the clutch plates in clean transmission fluid (Ford Specification Mercon® ESP-M2C1166-H) or equivalent, for 15 minutes.


Install pressure plate.



Install overdrive sun gear with short end of gear down into coast clutch cylinder.




## Overdrive Ring Gear And Center Shaft Assembly




### Disassembly


Remove inner race.




Remove small (inner) snap ring and one-way clutch assembly.




Remove large snap ring.




Remove thrust washer No. 7G400 from front of carrier.




Remove outer race assembly from ring gear.



Remove overdrive carrier from ring gear assembly.




Remove needle bearing assembly No. 7G128 from rear face of carrier, using screwdriver.



## Assembly


Install center shaft into overdrive ring gear.

Install center shaft to ring gear with retaining ring.




Remove center shaft to ring gear wave-type snap ring.


Remove center shaft from ring gear.




Install needle bearing assembly No. 7G128 on rear face of carrier.





Install overdrive carrier into center shaft and ring gear assembly.



Install outer race assembly into ring gear with snap ring groove facing up. Attach to ring gear with snap ring.




Install thrust washer No. 7G400 on front of carrier.






NOTE: E4OD overdrive one way clutch end caps must be installed as shown to achieve durability. The end cap with the scallops on the inner diameter must be toward the front of the transmission for proper lubrication.

Place top (thick) end cap onto one-way clutch.  
Place thin end cap onto bottom one-way clutch.




Install one-way clutch assembly. Date code on outside of thick end cap must be visible. Secure in place with snap ring.




Install inner race.

NOTE: Inner race must rotate counterclockwise.




## Intermediate/Overdrive Cylinder Assembly




## Disassembly


Using Clutch Spring Compressor Plate T89T-70010-F, Clutch Spring Compressor Bar T88C-77000-AH2 and Intermediate Clutch Spring Fixture T89T-7100-C or equivalent, compress the overdrive return spring.




Remove snap ring.




Remove outer and inner seals, using O-ring Tool T71P-19703-C or equivalent.




Remove compressor tool assembly.  
Remove return spring.




Remove intermediate piston.




Remove overdrive piston.




Remove intermediate/overdrive inner seal from cylinder bore, using O-Ring Tool T71P-19703-C or equivalent.



Remove outer seal from intermediate piston.




Install intermediate/overdrive inner seal into cylinder bore with lip seal facing down towards cylinder.




## Assembly


Install outer seal onto intermediate piston with lip seal facing down towards cylinder.




Install intermediate piston.




Install overdrive outer and inner seals with lip seal facing down towards cylinder.



Install overdrive piston.




Using Clutch Spring Compressor Plate T89T-70010-F Clutch Spring Compressor Bar T88C-77000-AH2 and Intermediate Clutch Spring Fixture T89T-70010-C or equivalents, compress return spring.




Install return spring.

NOTE: Spring fingers facing up.



Install snap ring.




Remove tool assembly.

## Center Support


### Disassembly

Remove two cast iron outer seal rings.



### Assembly


Install two cast iron seal rings.




## Forward Hub and Ring Gear

### Disassembly

Remove plastic thrust washer No. 7D090 from front face of hub.




Remove snap ring using screwdriver.






Remove forward hub from ring gear.




Install snap ring.




## Assembly


Install forward hub into gear.



Install plastic thrust washer No. 7D090 on the hub, using grease.




## Intermediate Brake Drum









### Disassembly

Remove outer race.




Remove one-way clutch assembly and end caps.







Install Clutch Spring Compressor Tool T65L-77515-A or equivalent and remove return spring snap ring.




Remove piston from intermediate brake drum.



Remove return spring assembly.




Remove inner and outer seals from drum using O-Ring Tool T71P-19703-C or equivalent.




## Assembly


Install inner seal into cylinder with seal groove facing down.




Inspect piston check ball for freedom of movement. clean with solvent if necessary.  
Install piston into drum.




Install outer seal into intermediate brake drum with seal groove facing down.



Install return spring assembly.



Install return spring assembly. Using Clutch Spring Compressor Tool T65L-77515-A or equivalent. Install snap ring. Ensure protrusions on spring retainer are properly engaged with lugs on clutch piston.



## Specification:

1.52 - 1.15mm (0.060 - 0.045 inch)

## Selective Snap Rings:


### Selective Snap Rings

1.65 - 1.75mm (0.065 - 0.069 inch)

1.88 - 1.98mm (0.074 - 0.078 inch)


2.10 - 2.20mm (0.083 - 0.087 inch)

FEELER  
GAUGE




Install four plate clutch pack, starting with steel plate. Install pressure plate.

**NOTE:** Soak the clutch plates with clean transmission fluid (Ford Specification Mercon® ESA-M2C1166-H) or equivalent for fifteen minutes.




Install selective snap ring. Check stack-up using feeler gauge. If not within specification, install correct snap ring and recheck.

Install small brass thrust washer No. 7D428 on face of cylinder.






Install large brass thrust washer No. 7G401 on face of cylinder.




Install intermediate one-way clutch end cap, one-way clutch assembly, outer race, and outer end cap over inner race.

NOTE: Lip is up on one-way clutch.


NOTE: Install onto inner race so that the outer race turns counterclockwise.




Install outer race so that the race turns counterclockwise.




## Forward Clutch Assembly Disassembly







Remove needle bearing assembly from inner face of cylinder.



Remove needle bearing assembly No. 7F374.  
Remove both teflon seal/rings from grooves using O-Ring Tool T71P-19703-C or equivalent.









## Technical Service Information


Remove return spring.




Remove outer seal from piston.




Remove steel ring from piston groove.



Remove inner seal from the cylinder.









Remove piston from cylinder using an air nozzle.



### Assembly

Install inner seal in cylinder.






Install front pressure plate.  
Install cushion spring.  
Install four steel plates and four friction plates alternately, starting with a steel plate.

**NOTE:** Soak the clutch plates with clean transmission fluid (Ford Specification Mercon® ESP-M2C1166-H) or equivalent for fifteen minutes.

11. Install rear pressure plate.



Install selective snap ring.

Check stack-up clearance, using feeler gauge. If not within specification install correct snap ring and recheck.

## Stack Up Clearance Specification:

1.40 - 0.76mm (0.055 - 0.030 inch)

## Selective Snap Rings:


1.42 - 1.52mm (0.056 - 0.060 inch)

1.88 - 1.98mm (0.074 - 0.078 inch)


2.34 - 2.44mm (0.092 - 0.096 inch)

2.79 - 2.90mm (0.110 - 0.114 inch)


3.25 - 3.35mm (0.128 - 0.132 inch)



Install Teflon® seal rings in grooves.




Install needle bearing assembly no. 75374 over Teflon® seal snout.






Install needle bearing assembly on inner face of cylinder, with notched inner race facing outward.




Remove thrust washer No. 7D423 from front side of carrier.



## Forward Carrier

### Disassembly


Remove needle bearing assembly No. 7F078 from carrier.



### Assembly


Place thrust washer No. 7D423 on front side of carrier, using grease to hold in place.

NOTE: Thrust washer tabs go into carrier.




## Assembly


Install front thrust washer No. 7D423. Hold in place using grease.



Install rear thrust washer No. 7D423. Hold in place using grease.




## Reverse One-Way Clutch




## Disassembly

Remove reverse hub and needle bearing assembly No. 7E413 from reverse one-way clutch hub.




Remove brass thrust washer and rollers from reverse clutch hub.




## Assembly


Install one-way clutch rollers and brass thrust washer No. 7E194.



Remove snap ring from reverse one-way clutch hub.




Install snap ring onto one-way clutch hub.



Install needle bearing assembly No. 7E413 with smooth race surface facing up.

NOTE: Lightly grease thrust washer.


Remove inner piston seal.



## Reverse Clutch Piston


### Disassembly

Remove outer piston seal.




### Assembly

Install inner piston seal.




Install outer piston seal.



## Assembly


Install extension housing seal, using Extension Housing Seal Replacer T61L-7657-B or equivalent.



## Extension Housing

### Disassembly

Using Extension Housing Seal Remover T74P-77248-A and Slide Hammer T50T-100-A or equivalents, remove seal.




## ASSEMBLY OF SUBASSEMBLIES



### Assembly

Place thrust washer No. 7D428 onto intermediate brake drum.

NOTE: Lightly grease thrust washer.




Install forward clutch onto intermediate brake drum.




Install needle bearing assembly 7F078 onto intermediate brake drum and forward clutch assembly.


NOTE: Lightly grease needle bearing assembly. Notched inner race facing outward (up).




Grease plastic thrust washer No. 7D090 and place onto forward clutch hub. Place forward clutch hub into intermediate brake drum and forward clutch assemblies.








INTERMEDIATE BRAKE DRUM,  
FORWARD CLUTCH  
ASSEMBLY AND FORWARD PLANET  
CARRIER ASSEMBLY




Grease thrust washer No. 7D423 and place onto forward planet carrier. Place carrier into assembly.



Install needle bearing assembly No. 7F078 into forward carrier assembly.


NOTE: Lightly grease needle bearing to hold in place. Notched inner race surface should face up.






## Technical Service Information

Align input shell notches with intermediate brake drum.




Install needle bearing assembly No. 7F374 into front end of forward clutch assembly.




Install input shell onto assembly.

**INTERMEDIATE BRAKE DRUM, FORWARD CLUTCH  
AND INPUT SHELL ASSEMBLY**



Install Intermediate Brake Drum, Forward Clutch and Input Shell Remover/Install T89T-70010-E or equivalent and proceed with transmission assembly.



### CLEANING AND INSPECTION

#### Transmission

Clean all parts with suitable solvent and use moisture-free air to dry off all parts and clean out fluid passages.

**The composition clutch plates, bands and synthetic seals should not be cleaned in a vapor degreaser or with any type of detergent solution.** To clean these parts, wipe them off with a lint-free cloth. New clutch plates or bands should be soaked in the specified transmission fluid for 15 minutes before being assembled.



## Technical Service Information

### SPECIFICATIONS

Description	Torque	
	N-m	ft-lbs
Inner O.W.C. Race to Case	24-34	(18-25)
Connector to Case (Fluid) Cooler Line	24-31	(18-23)
Plug Line Pressure Case	8-16	(6-12)
Plug — Throttle Pressure Case	8-16	(6-12)
Inner and Outer Lever to Manual Control Shaft	40-54	(30-40)
Positive Detent Spring to Case	9-11	(80-100 lb. in.)
Parking Rod Guide Plate to Case	22-27	(16-20)
Neutral Switch Assembly to Case	6-8	(55-75 lb. in.)
Center Support to Hub	9-14	(80-120 lb. in.)
Center Support Fluid Feed	11-16	(8-12)
Extension Housing to Case	27-39	(20-29)
Extension Housing to Case (4x2)	27-39	(20-29)
Extension Housing to Case (4x4)	27-39	(20-29)
Stator Support to Pump Body	9-11	(80-100 lb. in.)
Oil Pump Body to Case	24-31	(18-23)
Reinforcing Plate to Case	9-11	(80-100 lb. in.)
Main Accum. and Sol. Body to Case	9-11	(80-100 lb. in.)
Main and Lower Body to Case	9-11	(80-100 lb. in.)
Lower Body to Main Body	9-11	(80-100 lb. in.)
Sol. Body to Case	9-11	(80-100 lb. in.)
Park Rod Abutment to Case	22-27	(16-20)
Control Assembly to Pump	24-31	(18-23)
Oil Pan to Case	14-16	(10-12)
Converter Drain Plug	24-27	(18-20)
O/Drive Cylinder Fluid Feed	8-14	(6-10)
Stud — Valve Body to Case Short	9-11	(80-100 lb. in.)
Stud — Valve Body to Case Long	9-11	(80-100 lb. in.)
Nut — Valve Body to Case	9-11	(80-100 lb. in.)
Nut — Manual Detent Lever	41-54	(30-40)

### Installation of Cooling Lines

Transmission	Radiator		Transmission		Fluid Line Nut	
	ft-lbs	N-m	ft-lbs	N-m	ft-lbs	N-m
E4OD	8-12	11-16	18-23	24-31	12-18	17-24

### Fluid Capacity

Transmission Type	Liters	Quarts
4 x 2	16.4	15.5
4 x 4	16.9	16

## AUTOMATIC TRANSMISSION SERVICE GROUP