

BEDROCK BRACELETS INSTRUCTIONS







WHAT YOU WILL NEED

PVC PIPE* CUT INTO 1" THICKNESS
FINE SANDPAPER
HODGE PODGE GLUE (USED FOR DECOUPAGE)
BRUSH (TO APPLY HODGE PODGE)
SCISSORS
RIBBON

EXTRA STUFF

MAGAZINES
BUTTONS
FEATHERS
SPARKLES
FABRIC REMNANTS

INSTRUCTIONS

- 1** CUT THE PVC PIPE INTO THE THICKNESS OF BRACELET YOU'D LIKE, 3" IS GOOD FOR A NICE THICK BANGLE.
- 2**  USE SANDPAPER TO SMOOTH THE CUT EDGES/RIM.
- 3**  TAKE A LITTLE OF THE HODGE PODGE AND BRUSH IT ON THE INSIDE OF THE PIPE TO HOLD THE RIBBON DOWN. THEN WRAP THE RIBBON AROUND, OVERLAPPING IT A LITTLE. USE MORE HODGE PODGE TO SEAL THE END ONCE YOU'VE COMPLETELY COVERED THE PIPE.
- 4**  TAKE CLIPPINGS FROM MAGAZINES, BUTTONS, FEATHERS, SPARKLES OR WHATEVER YOU'D LIKE TO PUT ON YOUR BRACELET AND GLUE THEM TO YOUR BANGLE USING HODGE PODGE.
- 5**  LET IT DRY AND WEAR IT!